


## PARTS CATALOG

Onan Model
ENA ENAD
ENB ENBA
ENC
Generating Set



928-0228 2-92 (Spec A) Printed in U.S.A.

#### Introduction

This catalog applies to Onan Generator Models as listed in the Generator Set Data Table. Parts are arranged in groups of related items and each illustrated part is identified by a reference number corresponding to the same reference number in the parts list. Parts illustrations are typical. Unless otherwise mentioned in the description or page heading, parts are interchangeable between models. Throughout this catalog left and right sides are determined by facing the engine end (front) of the set.

Some parts list a second source for obtaining service replacement parts. A list of distributors and their addresses are located toward the rear of this catalog.

Engine parts that have been modified or added by Onan are identified in this catalog. All other engine replacement parts must be ordered from the engine manufacturer by referring to the engine manufacturer's nameplate and supplying all available information. Contact your nearest engine parts dealer for assistance in ordering replacement parts.

#### Replacement Engine

Onan/Cummins Generator Model	Ford Engine Model	Onan Replacement Engine No.
ENA	LSG-875	100-2249
ENB	LSG-875	100-2202
ENC	i. SG -875	100-2249
ENAD	LSG-875	100-2249
ENBA	LSG-875	100-2202

Replacement engines can be ordered from Onan. Order from your nearest Distributor.

#### Generator Set Data Table

ONAN MODEL &		ELECTRICAL DATA								
SPECIFICATION	WATTS	VOLTS	HERTZ	WIRE	PHASE	VOLTAGE				
50ENA/*	50,000	#	50	12	1 or 3	12				
60ENA/*	60,000		60	12	1 or 3	12				
54ENB/*	51,000	#	50	12	1 or 3	12				
65ENB/*	65,000		60	12	1 or 3	12				
58ENC/**	58,000	#	50	12	1 or 3	12				
70ENC/*	70,000		60	12	1 or 3	12				
56ENAD/*	56.000	#	50	12	1 or 3	12				
75ENAD/*	75.000		60	12	1 or 3	12				
75ENBA/*	75,000	#	50	12	1 or 3	12				
100ENBA/*	100,000		60	12	1 or 3	12				

The specification number denotes customer requested options or deviations from a standard model. The specification letter advances (E to F, F to G, etc.) with major manufacturing changes.

# - Broad range reconnectible.


#### Index

Gasket, Adapter - Thermostat 3,5,7 Actuator, Governor 13 Gasket, Body - Carburetor 15,17,19,21,23, 25,27,29,31
Gasket, flange - Exhaust 39
Gasket, Manifold - Exhaust 46 Adapter, Carburetor 15,17,19,21,23,27 29,31,39 Adapter, Exhaust 39 Adapter: Generator to Engine 3,5,7,85,87 Gasket, Pump - Fuel 15,17,19,21 Gauge, Pressure - Oil 71 Adapter, Pulley 51,53 Adapter, furbocharger Alternator 8,9 Ammeter 70,71,72 Gauge, Temperature - Oil 71 Gauge, Temperature - Water Gear, Ring 3,5,7 Generator 85,87,89 Governor, Electronic 13 Arm, Adjusting - Alternator 8,9 Band, Mounting - Exhaust Muffler 46,47 Base, Skid 65 Governor, Mechanical 11 Grille Assembly - Radiator Grommet 67,69,83,85,87 Bearing, 8all - Generator Bell, End - Generator 85,87 Guard, Belt 8,51,53,54,55,57 Guard, Fan 51,53,85,87 Guard, Radiator 51,53 Belt, Drive 8,9,11,51,53 Block, Terminal 3,5,7,61,69,83,85,87 Box, Control - Generator 67,69 Box, Entrance 91 Brace, Bracket - Fan Drive 51,53 Handle, Housing 63
Harness, Wiring 3,5,7,13,67,69,75,76,77, Bracket, Battery 65
Bracket, Drive - Fan 51,53
Bracket, Fuel - Remote 15,17,19,21,23,
25,27,29,31,33,35,37,39,41 79,80,90 Heater, Electrical 61,81
Heater, Electrical - Engine Coolant 66
Heater, Generator 83 Bracket, Guard - Belt 51,53,54 Bracket, Module - Ignition 65 Hose, Radiator 51,53,55,57,59 Hose, LPG 17,19,27,29,31,33,37,39 Hose, Rubber 3,5,7,17,19,21,23,27,31, 39,41,43,45,48,49,55,59,61 Bracket, Mounting - Alternator 8,9 Bracket, Mounting - Engine 65 Bracket, Mounting - Heater 61 Bracket, Mounting - Governor 11,13 Bracket, Mounting - Heat Exchanger 57,59 Breaker, Circuit 70,80,93 Housing, Connector Housing, Control 67 Housing, Set 63 Hub and Pulley Assembly 51,53 Cable, Electrical 81 Cap. Radiator 51,53 Carburetor, Gasoline 15,17,19,21 Carburetor, Vapor - Gas 17,19,21,23,25, Indicator, Service 39 Inlet, Cleaner - Air 44 27,29,31 Jacket, Air Heater 45 Joint, Ball 11,12 Chassis 65 Clamp, Loop 83 Cleaner, Air 42,43,44 Clip. Fastener 63 Cock. Orain 51,53,61 Key, Handle - Housing 63 Key, Machine - Rotor Assembly 85,87 Knob 70 Control, Engine 69 Control, Generator 69 Control, Heater 81 Light, Indicator 71,73,76 Line, Fuel - Flexible 15,17,19,21 Controller, Governor 13 Converter, Gas - LPG 19,25,31,35,41 Cooling System, Exchanger - Heat 57,59 Cooling System, Radiator 51,53 Cooling System, Radiator - Remote 54,55 Manifold, Exhaust 39,45
Meter, Frequency 70
Meter, Totalizing - Time 71
Meter, Watt 73,75
Mixon Air/Gas 21 Cooler, Oil 49.55,59 Cover, Bell - End 85 Cover, Thermostat 3,5 Mixer, Air/Gas 21 Module, Indicator - Fault Mount, Vibration 65,73 Decal, Warning - Shock Hazard 81 Dial, Wattmeter 75 Diode 69,85,87 Muffler, Exhaust 46,47 Nut, Insulating 65,85 Disk, Drive - Generator 85,87 Door, Control - Engine 69,71 Door, Control - Generator 69,70 Doors, Housing - Set 63 Panel, Box - Control Housing 67
Pencil, Zinc 57,59
Plate, Mounting - Heat Exchanger 57,59
Plate, Mounting - Terminal 3,5,7
Plate, Mounting - Toggle Switch 17
Potentiometer, Control - Speed 70,80 Element, Cleaner - Air 42,43,44 Exchanger, Heat 57,59 Exhaust System 45 Pulley, Crankshaft 51,53 Pulley, Alternator 8,9
Pulley, Water Pump 3,5,7
Pump, Fuel 15,17,19,21 Fan. Alternator 8,9 Fan. Radiator 51,53 Filter, Oil 48 Flywheel 3,5,7

Fuse, Cartridge 69


#### Index

Radiator 51,53 Radiator, Remote 54,55 Switch Pressure 29,31,41 Switch Pressure Low 013 3,5,7 Receptable Fastener 69
Regulator, Pressure - Gas 17,21,23,27, Switch Push - Reset/Pane: Lamp 71 Switch. Push - Run/Stop/Remote 71 29,31,33,37 Switch, Rotary 70 Relay 69,73,76,78 Switch, Thermostatic 3,5,7,61 Switch Toggle - Manual System 17,19,21 Switch Toggle - Manual System 17,18,18 System, Dual Fuel - Gasoline/LPG Liquid 19 Retainer Carburetor 44 Rod Throttle 11 Rotor Assembly Generator Rotor Exciter 85,87,90 System. Dual Fuel - Gasoline/LPG Vapor 21 System. Dual Fuel - Gasoline/Natural 85,87 Gas 17 System, Dual Fuel - cPG and Natural Sender: Pressure - Oil 3,5,7 Gas 29,31,37,41 Sender: Temperature - Engine Coolant Sender: Temperature - Cil 3,5,7 Sender: Speed - Magnetic 13 Shield: Heat - Exhaust Muffler 46,47 Shroud: Fan 51,53 System, Fuel - Gasoline 15 System, Fuel - Gaseous 23,25,27,33,35,39 3,5,7 Tachometer 72 Terminals 61,75,76
Terminal Eug - Ground 65
Thermostat 3,5,7,81
Transducer Watt 73,75
Transformer Current 77 Socket, Relay 76 Adjusting Arm - Alternator 8,9 Bracket - Fan Drive 51,53 Spacer. Spacer. Spacer Heater 81 Spacer Shield - Heat 46,47 Spacer Sleeve - Belt Guard 54,55 Tube, Exhaust 39,45
Tube, Exhaust - Flexible 46,47
Tube, Inlet - Radiator 51,53 Spacer, Sleeve - Governor 11 Spacer, Sleeve - Rotor 90 Turbocharger 39 Stator Assembly, Generator 85,87 Stator, Exciter 85,87,90 Strap, Electrical - Ground 65,69 Valve, Control - Temperature Regulating 57,59
Valve, Globe 57
Valve, PCV 3,5,7 Strap, Guard - Belt 55 Strap, Guard - Belt 55
Strap, Holddown - Heat Exchanger 57,59
Strap, Support 57
Strip, Marker 69
Stud 13,15,17,19,21,23,27,29,31,39
Stud, Fastener 69
Support, Grille - Radiator 51,53
Switch, Level - Low Coolant 66
Switch, Overspeed 85,87 lve, Solenoid 17,19,21,23,25,27,29, 31,33,35,37,41,57,59 Valve, Voltmeter 70,71 Wattmeter 75 Wrapper, Bell - End **85,89** Wrapper, Shroud - Radiator Fan **51,53** 




## Engine Accessories ENA, ENB, ENC

REF NO.	PART NO.	OTY USED	PART DESCRIPTION	REF NO.	PART NO.	OTY USED	PART DESCRIPTION
1	193-0244	1	Sender: Pressure - Oil	27	850-0045	7	Washer, Lock (5/16)
2 3	309- <b>0544</b> 309-05 <b>4</b> 5	1	Switch, Pressure - tow Oil Switch, Pressure - Low Oil	28	800-0039	1	Screw, Cap - Hex Head (5/16-18 x 3.5")
			(Pre-Alarm)	29	309-0477	ì	Cover, Housing - Thermostat
4	505 0763	1	Cross. Pipe (1/8 NPT)	30	309-0479	1	Gasket
5	505-0104	1	Nipple, Pipe (1/8 x 1.5)	31	309-0476	2	Thermostat (175°)
6	5 <b>05-0007</b>	1	Bushina, Reducer (1/4 x 1/8)	32	309-0478	1	Base, Housing - Thermostat
7	123-1905	1	Hose, Vent - Crankcase	33	130-0995	1	Gasket
8	502-0237	1	Elbow. Brass (1/2 x 3/8)	34	504-0005	1	Valve, Cock
ô	123-1904	ì	Valve. PCV	35	505-0131	1	Bushina, Reducer (3/4 x 3/8)
10	338-2787	ì	Harness, Wiring - Engine	36	309-0178	1	Switch, Thermostatic High
11	332-1292	, ,	Board, Terminal (Includes Parts Marked *)				Engine Coolant Temperature (S7)
12	8090036	1	*Screw, Thread Cutting - Round Head (#8 x 7/8")	37	309-0179	1	Switch, Thermostatic - High Engine Coolant Temperature
13	508~0015	1	*Washer, Insulating ~ Fiber				(Pre Heat)(S5)
			(#8)	38	502-0942	1	Elbow, Hose - 90"
14	870 -0196	ı	*Nut. Insulating (#8)	39	503-0547	2	Clamp, Hose
i <b>5</b>	332-1281	1	*Plate, Mounting - Terminal	40	503-0386	1	Hose, (5/8 ID x 12")
16	800 -0048	1	Screw, Cap - Hex Head	41	502-0943	1	Connector, Hose
			(3/8-16 x 3/4")	42	505-0019	1	Bushing, Reducer (1/2 x 3/8)
17	853-0018	i.	Washer, Lock - EIT (3/8")	43	132-0168	1	Pulley, Pump - Water
18	193-0249	1	Sender, Semperature - Oil (E5)	44	801-0027	4	Screw, Cap - Hex Head
19	505-0007	1	Bushing, Reducer (1/4 x 1/8)				(5/16-24 x .88)
20	309-0269	1	Switch, Thermostatic - Low	45	850-0045	4	Washer, Lock (5/16)
			Engine Temporature (S5)	46	812-0075	4	Screw, Round Head
21	800-0048	1	Screw, Cap - Hex Head				(#8-32 × 1/4")
			$(3/8-16 \times 3/4")$	47	191-0773	1	Cover. Hole - Stantan
22	193-0247	1	Sender, Temperature	48	231-0260	1	Adaptor, Generator
			Engine Coolant	49	800-0072	9	Screw, Hex Head
23	104-1097	1	Flywheel (Includes Ring Gear)				$(7/16-14 \times 1-1/4")$
24	104-0723	1	Gear. Ring	50	850-0055	9	Washer, Lock (7/16")
25	104-1771	6	Bolt. Locking (7/16-20 x 1.06")				
26	8000029	6	Screw, Cap - Hex Head (5/16-18 x 1.12")				




### Engine Accessories ENAD

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	193-0244	1	Sender, Pressure - Oil	26	800-0029	6	Screw, Cap - Hex Head
2	309-0544	1	Switch: Pressure - Low Oil				$(5/16-18 \times 1.12")$
3	30 <b>9-05</b> 45	1	Switch, Pressure - Low Oil	27	850-0045	7	Washer, Lock (5/16)
			(Pre-Alarm)	28	800-0039	1	Screw, Cap - Hex Head
4	505-0763	1	Cross, Pipe (1/8 NPT)				$(5/16-18 \times 3.5")$
5	505-0104	1	Nipple, Pipe $(1/8 \times 1.5)$	29	309-0477	1	Cover, Housing - Thermostat
6	505-0007	1	Bushing, Reducer (1/4 x 1/8)	30	309-0479	1	Gasket
7	123-1905	1	Hose, Vent - Crankcase	31	309-0476	2	Thermostat (175°)
8	502-0237	1	Elbow, Brass $(1/2 \times 3/8)$	32	309-0478	1	Base, Housing - Thermostat
9	123-1904	1	Valve, PCV		130-0995	1	Gasket
	338-2787	1	Harness, Wiring - Engine	34	504-0005	1	Valve, Cock
11	332-1292	, 1	Board, Terminal (Includes		505-0131	1	Bushing, Reducer (3/4 x 3/8)
			Parts Marked *)	36	309-0178	1	Switch, Thermostatic - High
12	809-0036	1	*Screw, Thread Cutting -				Engine Coolant Temp (S7)
			Round Head (#8 x 7/8")	37	309-0179	1	Switch, Thermostatic - High
13	508-0015	1	*Washer, Insulating - Fiber (#8)				Engine Coolant Temperature (Pre Heat) (S5)
14	870-0196	1	*Nut, Insulating (#8)	38	502-0942	1	Elbow, Hose - 90*
15	332-1281	ī	*Plate, Mounting - Terminal	39	503-0347	2	Clamp, Hose
16	800-0048	ī	Screw, Cap - Hex Head	40	503-0386	ī	Hose, (5/8 ID x 12")
			$(3/8-16 \times 3/4")$	41	502-0943	ī	Connector, Hose
17	853-0018	1	Washer, Lock - EIT (3/8")		505-0019	ī	Bushing, Reducer (1/2 x 3/8)
18	193-0249	1	Sender, Temperature - 0il	43	502-0058	1	Tee, Pipe - Street (1/8 NPT)
			(E5)		132-0261	i	Pulley, Pump - Water
19	505-0007	1	Bushing - Reducer (1/4 x 1/8)		131-0353	1	Spacer, Pulley - Water Pump
20	309-0269	1	Switch, Thermostatic - Low Engine Temperature (S5)	46	801-0027	4	Screw, Cap - Hex Head (5/16-24 x .88)
21	800-0048	1	Screw, Cap - Hex Head	47	850-0045	4	Washer, Lock (5/16")
			$(3/8-16 \times 3/4^{\circ})$		231-0260	ī	Adaptor, Generator
22	193-0247	1	Sender, Temperature - Engine		812-0075	ī	Screw, RHM (#8-32 x 1.25)
			Coolant	50	800-0072	9	Screw, Hex Head
23	104-1097	1	Flywheel (Includes Ring Gear)			-	$(7/16-14 \times 1-1/4")$
24	104-0723	1	Gear, Ring	51	850-0055	9	Washer, Lock (7/16")
25	104-1771	6	Bolt, Locking (7/16-20 x 1.06")		191-0773	1	Cover, Hole - Starter




### Engine Accessories ENBA

REF NO.	PART NO.	OTY USED	PART DESCRIPTION	REF No.	PART NO.	OTY USED	PART DESCRIPTION
1	193-0244	1	Sender. Pressure - Oil	28	800-0039	1	Screw. Cab - Hex Head
2	309-0544	ì	Switch, Pressure - Low Oil				(5/16-18 x 3.5")
3	309~0545	í	Switch, Pressure - Low Oil	29	309-0477	1	Cover, Housing - Thermostat
			(Pre-Alarm)	30	309-0479	1	Gasket
4	505-0763	1	Cross, Pipe (1/8 NPT)	31	309-0476	2	Thermostat (175°)
5	505 0104	1	Nipple, Pipe (1/8 x 1.5)	32	309-0478	1	Base. Housing - Thermostat
6	505-0007	1	Bushing, Reducer (1/4 x 1/8)	33	130-0995	1	Gasket
10	338-2786	1	Harness. Wiring - Engine	34	504-0005	1	Valve, Cock
ī 1	332-12 <b>9</b> 2	i	Board, Terminal (Includes	35	505-0131	1	Bushing, Reducer (3/4 x 3/8)
			Parts Marked *)	36	309-0178	1	Switch, Thermostatic - High
12	809-0036	1	*Screw, Thread Cutting - Round Head (#8 x 7/8")				Engine Coolant Temperature (S7)
13	508-0015	· 1	*Washer. Insulating - Fiber (#8)	37	309-0179	1	Switch, Thermostatic - High Engine Coolant Temperature
14	870-0196	1	*Nut, Insulating (#8)				(Pre Heat) (S5)
15	332-1281	1	*Plate, Mounting - Terminal	38	502-0942	1	Elbow, Hose - 90°
16	800-0048	1	Screw, Cap - Hex Head	39	503 0547	2	Clamp, Hose
			$(3/8-16 \times 3/4")$	40	503-0386	1	Hose. $(5/8 \text{ IO} \times 12^{\circ})$
17	853-0018	1	Washer, Lock - EIT (3/8")	41	502-0943	1	Connector, Hose
18	193~0249	1	Sender, Temp - Oil (E5)	42	505-0019	1	Bushing, Reducer (1/2 x 3/8)
19	505-0007	1	Bushing - Reducer (1/4 x 1/8)	43	2310260	ì	Adapter, Generator
20	309-0269	ì	Switch, Thermostatic - Low	44	191-0773	1	Cover. Hole - Starter
			Engine Temperature (S5)	45	812-0075	1	Screw. Round Head
21	800-0048	1	Screw. Cap - Hex Head				(#8-32 x 1/4")
	100 0045		$(3/8-16 \times 3/4")$	46	800-0072	6	Screw, Hex Head
22	193-0247	1	Sender, Temperature - Engine				$(7/16-14 \times 1-1/4")$
			Coolant	47	800-0055	6	Washer, Lock (7/16")
23	104-1097	1	Flywheel (Includes Ring Gear)		502-0058	1	Tee. Brass (1/8")
24	104-0723	1	Gear, Ring		132-0261	1	Pulley. Pump - Water
25	104-1771	6	Bolt, Locking		131-0353	i.	Spacer, Pulley - Water Pump
			$(7/16-20 \times 1.06")$	51	801-0027	4	Screw, Cap - Hex Head
26	800-0029	6	Screw, Cap - Hex Head				(5/16-24 × .88")
			(5/16-18 x 1.12")	52	850-0045	4	Washer, Lock (5/16")
27	850-0045	7	Washer, Lock (5/16)				




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	OTY USED	PART DESCRIPTION
i	191-1983-01	1	Alternator	17	800-0029	1	Screw. Cap - Hex Head
2	191-1203	1	Bracket, Adjusting -				(5/16·18 x 1.12")
-		-	Alternator	18	191-0864	1	Spacer
3	526-2106	1	Washer, Flat (M8)	19	850-0050	5	Washer, Lock (3/8)
4	800-2008	1	Washer, Lock (M8)	20	800-0052	1	Screw, Cap - Hex Head
5	800-2058	1	Screw, Hex Hoad				$(3/8-16 \times 1.5")$
			(M8 × 1.25 × 25mm)	21	130-0988	1	Spacer
6	850-2005	2	Washer, Lock (M5)	22	130-3315	1	Guard, Belt
7 ·	860-2006	2	Nut, Hex (M5)	23	821-0029	2	Screw. Self Lockina - Hux
8	850-2008	1	Washer, Lock (M8)				Head
9	860~2008	1	Nut, Hex (M8)				$(3/8-16 \times .75")$
10	191-1982	1	Pulley, Alternator	24	870-0281	2.	Nut, Lock 3/8-16)
11	511-0084	1	Belt, Drivo	25	191 2026	1	Bracket, "Gunting
12	851-0039	1	Washer, Spring (M16)	26	8000069	1	Screw. Ca - Hex Head
13	870-2161	1	Nut, Hex (M16 x 1.5)				(7/16-14 x .75)
14	191-1981	ì.	Fan, Alternator	27	850-0055	1	Washer, Lock (7/16")
15	862-0015	1	Nut, Hex (5/16-18)	28	800-0048	1	Screw. Cap - Hex Head
16	850~0045	ī	Washer, Lock (5/16)				(3/8-16 × .75")

#### Alternator ENBA



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.		QTY USED	PART DESCRIPTION
1	511-0092	1	Belt, Orive	15	850-0050	3	Washer, Lock - Spring (3/84)
2	191-2032	1	Pulley, Alternator	16	191-2028	1	Spacer, Mounting - Alternator
3	800-2058	1	Screw, Cap - Hex Head	17	191-2031	1	Bracket, Mounting
			$(M8 \times 1-1/4 \times 25mm)$	18	191-1981	1	Fan, Alternator
4	850-2008	2	Washer, Lock - Spring (M8)	19	526-0029	1	Washer, Flat (3/8")
5	526-2106	ī	Washer, Flat (M8)	20	370-4038	2	Spacer, Arm - Adjusting
6	800-0054	Ī	Screw, Cap - Hex Head	21	851-0039	1	Washer, Lock - Spring (M16)
		-	(3/8-16 x 2")	22	870-2161	1	Nut, Hex Washer Head -
7	850-0050	1	Washer, Lock - Spring (3/8")				Self-Locking (M16)
8	191-0101	ī	Arm, Adjusting - Alternator	23	850-2006	2	#Nut, Hex (M5)
9	800-2097	ï	Screw, Cap - Hex Head	24	850-2005	2	Washer, Lock - Spring (115)
-		_	$(M10 \times 1-1/2 \times 80mm)$	25	860-2008	1	*Nut, Hex (M8)
10	850-0060	1	Washer, Lock - Spring (1/2")	26	850-0055	1	Washer, Lock (7/16")
11	870-2056	i	Nut, Hex Washer Head -	27	800-0069	ī	Screw, Cap - Hex Head
**	0.0 2000	•	Self-Locking			-	$(7/16-14 \times 3/4^{*})$
			$(M10 \times 1 - 1/2^{H})$	28	800-0048	1	Screw, Cap - Hex Head
12	191-1983-01	1	Alternator		****	_	$(3/8-16 \times 3/4")$
13	312-0201	î	Capacitor				(5,0 00 11 5,1 7
14	800-0058	i	Screw, Cap - Hex Head				
14	000 0030	•	(3/8-16 x 3")				


- # Used to attach the wiring harness to the alternator D+ terminal and to attach the ground wire to one of the four alternator housing sduds
- \* Used to attach the wiring harness lead to the B+ terminal of the alternator



### Mechanical Governor

REF NO.	PART NO.	OTY USED	PART Description	REF NO.	PART NO.	OTY USED	PART DESCRIPTION
1	511-0084	1	Beit, Drive - V	9	800-0052	l	Screw. Cap - Hex Head
2	115-0025	4	Nut. Hex (1/4-28)				(3/8-16 x 1-1/2")
3	850-0040	2	Washer, Lock - Spring (1/4")	10	850-0050	1	Washer, Lock - Spring (3/8")
4	150-0638	2	Joint, Ball	11	130-0988	1	Spacer. Sleeve
5	152-0243	1	Rod, Throttle	12	800-0048	1	Screw. Cap Hex Head
6	821-0030	3	Screw. Hex Washer Head -				(3/8-16 x 3/4")
			Self-Locking (3/8-16 x 1")	13	850-0050	1	Washer, Lock - Spring (3/8")
7	870-0281	3	Nut. Hex Washer Head Self-Locking (3/8-16)	14	800-0069	1	Screw. Cap - Hex Head (7/16-14 x 3/4")
8			Governor	15	850-0055	1	Washer, Lock - Spring (7/16")
	151-0627	1	ENA, ENB, ENC	16	191-2025	1	Bracket, Mounting
	151-0584	'1	ENAD	17	151-0594	1	Spring, Governor - 50 Hz Only


#### Electronic Sovernor



#### Electronic Governor

REF NO.	PART NO.	OTY USED	PART DESCRIPTION	REF No.	PART NO.	OTY USED	PART DESCRIPTION
ì	115-0025	4	Nut. Hex (1/4-28)	12	813-0098	4	Screw, Machine - Round Head
2	150-1995	2	Joint, Ball				(#10-32 x 3/8")
3	520-0967	1	Stud	13	850-0030	4	Washer, Lock - Spring (#10)
4	150-2145	1	Lever	14	800-0054	1	Screw, Cap - Hex Head
5	151-0625	1	Actuator				(3/8-16 × 2")
6	151 0624	1	Controlier	15	526 -0030	1	Washer, Flat
7	150-2163	1	Bracket, Mounting	16	850~0050	1	Washer, Lock - Spring (3/8")
8	338-2791	1	Harness. Wiring - Governor	17	850 -0055	1	Washer, Lock - Spring (7/16")
9	151-0433	1	Pick-Up. Magnetic	18	800-0072	1	Screw, Cap - Hex Head
10	8000-0008	4	Screw, Cap - Hex Head				$(7/16-14 \times 1-1/4)$
			(1/4-20 x 1.25")	19	80° JJ91	1	Screw. Cap - Hex Head
11	870 -0212	4	Nut . Hex Washer liead				$(1/2-13 \times 1-1/4)$
			Self Locking (1/4-20)	20	850-0060	1	Washer, Lock - Spring (1/2")


Fuel System Gasoline ENA, ENB, ENC



#### Fuel System Gasoline ENA, ENB, ENC


REF NO.	PART NO.	OTY USED	PART DESCRIPTION	REF NO.	PART NO.	OTY USED	PART DESCRIPTION
_	141-0841	1	Carburetor	12	148-0966	1	Bracket, Fuel Remote
2	502-0042	1	Elbow. Male ~ Inverted	13	505-0054	2	Plug. Square Head (1/4)
			$(1/8 \text{ NPT} \times 1/2-20)$	14	821-0016	2	Screw, Self-Locking
3	149-2297	1	Line, Fuel - Upper				$(5/16-18 \times 3/4")$
4	149-1774	1	Filter, Fuel Includes Hos	ses 15	104-0091	2	Nut. Hex (3/8-24)
			and Clamps	16	854-0020	2	Washer, Lock (3/8")
5	149-2298	1	line, Fuel - Lower	17	141-0852	1	Gasket, Carburetor
6	502 -0004	l	Elbow, Male - Inverted	18	114-0022	2	Screw. Hex Head
			(1/4 NPT x 1/2-20)				$(5/16-18 \times 1.75")$
7	149-2296	1	Pump, Fuel	19	850-0045	2	Washer, Lock (5/16")
8	149-1436	1	Gasket, Pump - Fuel	20	520-0311	2	Stud $(3/8-16 \times 1.5/8")$
9	502-0041	1	Elbow, Male Inverted	21	145-0482	1	Adapter, Carburetor
			(1/4 NPT x 7/16-24)	22	110-0445	4	Nut, Hex (5/16-24)
10	501-0103	1	Line, Fuel - Flex	23	526-0065	4	Washer, Flat (5/16)
			$(1/4 \text{ NPT} \times 7/16-24)$	24	520-0972	4	Stud $(5/16 \times 3.1/4)$
11	505-0020	3	Bushina, Reducer $(3/4 \times 1/4)$	1)			

Fuel System Gasoline/Natural Gas ENA, ENB, ENC



#### Fuel System Gasoline/Natural Gas ENA, ENB, ENC


REF NO.	PART NO.	OTY USED	PART DESCRIPTION	REF NO.	PART NO.	OTY USED	PART DESCRIPTION
i	148-0764	1	Carburetor, Natural Gas	25	149-2297	ì	Line, Fuel - Upper
2	505-0106	2	Nipple, Pipe (1/2 x 1-1/2)	26	502-0042	1	Elbow, Male - Inverted
3	505-0040	1	Elbow. Pipe (1/2 x 90°)				(1/8 NPT x 1/2-20)
4	505-0022	1	Bushing, Reducer (1" x 1/2")	27	141-0841	1	Carburetor (Includes Parts
5	148-0601	1	Regulator, Natural Gas				Marked *)
			(1" NPT)	28	141-0911	1	*Cover, Chake w/Heater 12VDC
6	505-0129	1	Bushing, Reducer (1" x 3/4")	29	141-0850	1	*Solenoid, Fuel Cutoff 12VDC
7	505-0102	2	Nipple, Close (3/4 x 1-3/8)	30	141-0852	1	*Gasket
8	307- 0834	1	Valve, Solenoid (3/4 NPT)	31	104-0091	2	Nut, Hex (3/8-24)
9	505-0132	1	Elbow, Pipe (3/4 x 90°)	32	854-0020	2	Washer, Lock (3/8")
10	502-0971	2	Connector, Hose (1"ID Hose)	33	520-0311	2	Stud (3/8-24 x 1-5/8")
11	503-0396	2	Clamp, Hose	34	145-0482	1	Adapter, Carburetor
12	503-1103	1	Hose, LPG (1" x 52")	35	520-0972	4	Stud (5/16-24 x 3-1/4")
13	148-0967	1	Bracket, Fuel - Remote	36	110-0445	4	Nut. Hex (5/16-24)
14	505-0130	1	Plug, Square Head (3/4)	37	526-0065	4	Washer, Flat (5/16")
15	821-0016	2	Screw, Self-Locking	38	503-0542	1	Hose, Adaptor
			(5/16-18 x 3/4")	39	503-0399	2	Clamp, Hose - T-Bolt (2-3/4")
16	505-0020	1	Bushing, Reducer (3/4 x 1/4)	40	306-0155	1	Bracket. Mounting
17	501-0103	1	Line, Fuel - Flex	41	308-0150	1	Plate, Mounting - Switch
			(1/4 NPT x 7/16-24)	42	813-0098	2	Screw. Round Head
18	504-0007	1	Cock, Shut-Off				(10-32 × 3/8")
			(1/8 NPT x 7/16-24)	43	870-0131	2	Nut. Lock - External Tooth
19	505-0007	1	Bushing, Reducer (1/4 x 1/8)				(10-32)
20	149-2296	1	Pump, Fuel	44	308-0005	1	Switch, Togale
21	149-1436	1	Gasket. Pump - Fuel	45	114-0022	2	Screw. Cap - Hex Head
22	502-0004	1	Elbow, Male " Inverted				(5/16-18 x 1-3/4")
			$(1/4 \text{ NPT} \times 1/2-20)$	46	850- <b>0045</b>	2	Washer, Lock (5/16")
23	149-2298	1	Line, Fuel - Lower				
24	149-1774	1	Filter, Fuel (Includes Hoses and Clamps)				



#### Fuel System Gasoline/Liquid Propane ENA, ENB, ENC

REF NO.	PART NO.	OTY USED	PART DESCRIPTION	REF NO.	PART NO.	OTY USED	PART DESCRIPTION
1	148-0764	î	Carburetor, Natural Gas	34	306-0155	1	Bracket, Mounting - Switch
2	505-0106	1	Nipple, Pipe $(1/2 \times 1-1/2)$	35	308-0150	1	Plate, Mounting - Switch
3	505-0268	1	Nipple. Pipe $(3/4 \times 5-1/2)$	36	308-0005	1	Switch, Togale
4	505-0021	1	Bushing, Reducer (3/4 x 1/2)	37	870-0131	2	Nut, Hex - External Tooth
5	505-0132	2	Elbow, Pipe (3/4 x 90°)				(#10-32)
6	141 0852	1	Gasket. Carburetor - Natural Gas	38	813-0098	2	Screw, Round Head (10-32 x 3/8")
7	5030542	1	Hose, Adapter (2.25 x 1.25)	39	502-0971	2	Connector, Hose (1"ID Hose)
8	503-0999	2	Clamp, Hose - T-Bolt (2.75")	40	503-039B	2	Clamp, Hose
9	141-0841	1	Carburetor, Gasoline (Includes	41	503-1103	1	Hose, LPG (1"ID x 34")
			Parts Marked *)	42	505-0132	1	Elbow, Pipe (3/4 x 90°)
10	141-0911	1	*Cover, Choke w/Heater 12VDC	43	505~0084	i	Nipple, Pipe (3/4 x 2-1/2)
11	141-0850	1	*Solenoid, Fuel Cutoff 12VDC	44	505-0661	1	Tee. Reducing
12	141-0852	1	*Gasket . Carburetor				$(1" \times 1" \times 3/4")$
13	104-0091	2	Nut . Hex (3/8-24)	45	505-0331	1	Nipple, Pipe (1" x 4")
14	854-0020	2	Washer, Lock - Internal Tooth	46	505-0479	1	Cap, Pipe (1")
			(3/8")	47	505-0004	1	Nipple, Close (1" x 1-1/2")
15	520-0311	2	Stud (3/8-24 x 1-5/8")	48	501-0608	1	Hose, Fuel - LPG
16	145-0482	ī	Adapter, Carburetor				$(3/8 \text{ ID} \times 28")$
17	520-0972	4	Stud (5/16-24 x 3-1/4")	49	505-1463	1	Elbow, Male - 90"
18	526-0065	4	Washer, Flat (5/16")				$(1/4 \text{ NPT} \times 9/16-18)$
19	110-0445	4	Nut. Hex (5/16-24)	50	307-0268	1	Valve. Solenoid
20	502-0042	1	Elbow, Male - Inverted	51	505-0099	1	Nipple, Pipe (1/4 x .88)
			(1/8 NPT x 1/2-20)	52	503-0547	2	Clamp, Hose
21	149-2297	1	Line, Fuel - Upper	53	502-0943	2	Connector, Huse (5/8 ID Hose)
22	149-1774	1	Filter, Fuel (Includes Hoses	54	503-0386	1	Hose (5/8 ID x 20)
			& Clamps)	55	503-0386	1	Hose (5/8 ID x 30)
23	149-2298	1	Line, Fuel - Lower	56	148-0625	1	Convertor, Gas
24	502-0004	1	Elbow, Male - Inverted	57	148-0773	1	Bracket. Convertor
			(1/4 NPT x 1/2-20)	58	148-0776	1	Spacer
25	149-2296	1	Pump. Fuel	59	800-0051	1	Screw. Cao - Hex Head
26	149-1436	1	Gasket. Pump - Fuel				$(3/8-16 \times 1-1/4")$
27	504-0007	1	Cock, Shut-Off	60	850-0050	1	Washer, Lock (3/8")
			(1/8 NPT × 7/16-24)	61	505-0101	1	Nipple, Close (3/8 x 1)
28	505-0007	1	Bushing, Reducer (1/4 x 1/8)	62	505-0039	1	Elbow, Pipe (3/8 x 90°)
29	501-0103	1	Line. Fuel - Flex (1/4 NPT x 7/16-24)	63	800-0049	2	Screw. Cap - Hex Head (1/4-20 x 3/4")
30	505-0020	6	Bushing, Reducer (3/4 x 1/4)	64	850-0040	2	Washer, Lock (1/4")
31	505-0054	4	Plug. Square Head (1/4")	65	800-0069	2	Screw, Cap - Hex Head
32	148-0967	1	Bracket, Fuel - Remote				(7/16-14 × 3/4")
33	821-0016	2	Screw. Self-Locking (5/16-18 x .75")	66	850-0055	2	Washer, Lock (7/16")


#### Fuel System Gasoline/Propane Vapor ENA, ENB, ENC



#### Fuel System Gasoline/Propane Vapor ENA, ENB, ENC


REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	148-0764	1	Carburetor, Natural Gas	24	149-2298	1	Line, Fuel - Lower
2	148-0636	1	Regulator, LPG (1"NPT)	25	149-1774	1	Filter, Fuel w/Hoses & Clamps
3	307-0834	1	Valve, Solenoid (3/4"NPT)	26	149-2297	1	Line, Fuel - Upper
4	505-0106	2	Nipple, Pipe (1/2 x 1-1/2)	27	502-0042	1	Elbow, Male - Inverted
5	505-0102	2	Nipple, Close $(3/4 \times 1-3/8)$				$(1/8 \text{ NPT} \times 1/2-20)$
6	505-0021	1	Bushing, Reducer $(3/4 \times 1/2)$		141-0841	1	Carburetor
7	505-0108	1	Tee, Pipe (1/2")	29	141-0852	1	Gasket, Carburetor
8	505-0129	2	Bushing, Reducer (1" x 3/4")	30	104-0091	2	Nut, Hex (3/8-24)
9	505-0132	1	Elbow, Pipe (3/4 × 90°)	31	854-0020	2	Washer, Lock (3/8")
10	505-0056	1	Plug, Pipe (1/2")	32	503-0542	1	Adapter, Hose $(2-1/4 \times 1-1/4)$
11	502-0971	2	Connector, Hose (1"ID Hose)	33	503-0999	2	Clamp, Hose - T-Bolt (2-3/4")
12	503-0398	2	Clamp, Hose		520-0311	2	Stud $(3/8-16 \times 1-5/8")$
13	503-1103	1	Hose (1"ID x 52")		145-0482	1	Adapter, Carburetor
14	148-0967	1	Bracket, Fuel - Remote		110-0445	4	Nut, Hex (5/16)
15	505-0130	4	Plug, Square Head (3/4")	37	526-0065	4	Washer, Flat (5/16")
16	821-0016	2	Screw, Self-Locking	38	520-0972	4	Stud $(5/16-24 \times 3-1/4")$
			$(5/16-18 \times 3/4")$	39	306-0155	1	Bracket
17	505~0020	1	Bushing, Reducer (3/4 x 1/4)	40	308-0150	1	Plate, Mounting - Switch
18	501-0103	1	Line, Fuel - Flex	41	308-0005	1	Switch, Toggle
			$(1/4 \text{ NPT} \times 7/16-24)$	42	813-0098	. 2	Screw, Round Head
19	504-0007	1	Cock, Shut-Off				(#10-32x3/8")
			$(1/8 \text{ NPT} \times 7/16-24)$	43	870-0131	2	Nut, Lock - External Tooth
20	505-0007	1	Bushing, Reducer (1/4 x 1/8)				(#10-32)
21	149-2296	1	Pump, Fuel	44	520-0311	2	Stud $(3/8-24 \times 1-1/2")$
				45	520-0972	4	Stud $(5/16 \times 3-1/4")$
22	149-1436	1	Gasket, Pump - Fuel	46	526-0065	4	Washer, Flat (5/16")
23	502-0004	1	Elbow, Male Inverted	47	110-0445	4	Nut, Hex (5/16-24)
			$(1/4 \text{ NPT} \times 7/16-24)$	48	145-0608	1	Adapter, Carburetor

Fuel System Natural Gas ENA, ENB, ENC



#### Fuel System Natural Gas ENA, ENB, ENC


REF NO.	PART NO.	OTY USED	PART DESCRIPTION	REF NO.	PART NO.	OTY USED	PART DESCRIPTION
1	148-0763	1	Carburetor, Natural Gas	13	148-0966	1	Bracket, Fuel - Remote
2	141-0852	1	Gasket, Carburetor	14	503-1103	1	Hose (1"ID x 44")
3	505-0106	2	Nipple, Pipe $(1/2 \times 1/2)$	15	505-0130	2	Plug. Square Head (3/4)
4	505-0040	1	Elbow. Pipe (1/2 × 90°)	16	821-0016	2	Screw. Self-Locking
5	505-0022	ï	Bushing Reducer (1" x 1/2")				$(5/16-18 \times 3/4")$
6	148-0601	1	Regulator, Natural Gas (1"NPT)	17	104-0091	2	Nut. Hex (3/8-24)
7	505-0129	1	Bushing, Reducer (1" x 3/4")	18	854-0020	2	Washer, Lock (3/8")
8	505-0102	2	Nipple, Close (3/4 x 1-3/8)	19	110-0445	4	Nut. Nex (5/16-24)
9	307-0834	ï	Valve, Solenoid (3/4 NPT)	20	526-0065	4	Washer, Flat 5/16")
10	505-0132	ī	Elbow. Pipe (3/4 x 90°)	21	145-0482	1	Adapter, Carburetor
11	502-0971	Ž	Connector, Hose (1"ID Hose)	22	520-0311	4	Stud (5/16-24 x 1-1/2")
12	E02-0200	-	Clama Hans				



#### Fuel System Liquid Propane ENA, ENB, ENC

REF NO.	PART NO.	OTY USED	PART DESCRIPTION	REF NO.	PART NO.	OTY USED	PART DESCRIPTION
1	148-0763	1	Carburetor, Natural Gas	21	800~0051	1	Screw. Cap - Hox Head
2	141-0852	1	Gasket, Carburetor			_	$(3/8-16 \times 1-1/4^{\circ})$
3	505-0106	1	Nipple, Pipe (1/2 x 1-1/2)	22	<b>650-0050</b>	1	Washer, Lock (3/8")
4	505-0021	1	Bushing, Reducer (3/4 x 1/2)	23	502-0943	2	Connector, Hose (5/8"ID Hose)
5	505-0132	2	Elbow. Pipe (3/4 x 90")	24	503-0547	2	Clamp, Hose
6	505-0268	1	Nipple, Pipe (3/4 x 5-1/2)	25	505-0039	1	Elbow, Pipe (3/8 x 90")
7	5020971	2	Connector, Hose (1"ID Hose)	26	505-0101	1	Nipple, Close (3/8 x 1)
8	503-0398	2	Clamp, Hose	27	505-0099	1	Nipple, Pipe (1/4 x .88)
9	503-1103	1	Hose (1"ID x 21")	28	307-0268	1	Valve. Solenoid
10	148-0625	ī	Convertor Assv. Gas	29	850-0040	2	Washer, Lock (1/4")
11	148-0773	î	Bracket Assy, Convertor - Gas	30	800-0049	2	Screw. Cap - Hex Head
12	800-0069	2	Screw. Cap - Hex Head	• • •			$(1/4-20 \times 3/4)$
		_	$(7/16-14 \times 3/4")$	31	505-0004	1	Nipple, Close (1" x 1-1/2")
13	850~0055	2	Washer Lock (7/16")	32	505-0661	ī	Tee, Reducing
14	505-1463	1	Elbow, Male - 90"				$(1" \times 1" \times 3/4")$
			(1/4 NPT x 9/16-18)	33	505-0331	1	Nipple, Pipe (1" x 4")
15	501-0608	1	Hose, Fuel - LPG	34	505-0479	1	Cap. Pipe (1")
			(3/8"ID x 28")	35	505-0084	1	Nipple, Close (3/4 x 2-1/2)
16	505-0020	3	Bushing, Reducer (3/4 x 1/4)	36	505-0132	ĩ	Elbow. Pipe (3/4 x 90°)
17	505-0064	Ī	Plug. Square Head (1/4)	37	503 -0386	1	Hose, (5/8"ID x 30")
18	148-0966	ä	Bracket, Fuel - Remote	38	503-0386	1	Hose (5/8"ID x 20")
19	821-0016	2	Screw, Self-Locking	39	854-0020	2	Washer, Lock (3/8")
		_	$(5/16-18 \times 3/4^{\circ})$	40	104-0091	2	Nut. Hex (3/8-24)
20	148-0776	1	Spacer			_	


Fuel System Propane Vapor ENA, ENB, ENC



#### Fuel System Propane Vapor ENA, ENB, ENC

REF NO.	PART NO.	OTY U <b>S</b> ED	PART DESCRIPTION	REF NO.	PART NO.	OTY USED	PART DESCRIPTION
1	148-0763	1	Carburetor, Natural Gas	14	503-1103	1	Hose, LPG (1"ID x 43")
2	148-0636	1	Regulator, LPG (1"NPT)	15	148-0966	1	Bracket, Fuel - Remote
3	307-0834	ī	Valve, Solenoid (3/4"NPT)	16	505-0130	Ž	Plug. Square Head (3/4)
4	505-0106	2	Nipple, Pipe $(1/2 \times 1-1/2)$		821-0016	2	Screw. Self-Locking
5	505-0102	2	Nipple, Pipe (3/4 x 1-3/8)	- '		_	(5/16-18 x 3/4")
6	505-0021	1	Bushing, Reducer (3/4 x 1/2)	18	104-0091	2	Nut, Hex (3/8-24)
7	505-0129	2	Bushing, Reducer (1 x 3/4)	19	854-0020	2	Washer, Lock (3/8")
8	505-0108	ī	Tee, Pipe (1/2)	20	520-0311	2	Stud (3/8 x 1-1/2")
9	505-0132	ī	Elbow, Pipe (3/4 x 90°)	21	145-0482	1	Adapter, Carburetor
10	505-0056	ī	Plug. Pipe (1/2)	22	110-0445	4	Nut. Hex (5/16-24)
11	141-0852	1	Gasket . Carburetor	23	526-0065	4	Washer, Flat (5/16")
12	502-0971	2	Connector, Hose (1"ID Hose)	24	520-0972	4	Stud (5/16-24 x 3-1/4")
13	503-0398	2	Clamp Hore			•	


## Fuel System LPG Vapor/Nautral Gas Automatic Changeover ENA, ENB, ENC



# Fuel System LPG Vapor/Nautral Gas Automatic Changeover ENA, ENB, ENC


REF NO.	PART NO.	OTY USED	PART DESCRIPTION	REF No.		OTY USED	PART DESCRIPTION
1	148-0763	1	Carburetor, Natural Gas	18	148-0967	1	Bracket, Fuel - Remote
2	141-0852	ì	Gasket, Carburetor	19	821-0016	3	Screw, Self-Locking
3	505-0106	1	Nipple, Pipe (1/2 x 1-1/2)				$(5/16-18 \times 3/4")$
4	505-0021	1	Bushing, Reducer (3/4 x 1/2)	20	502-0971	4	Connector, Hose (1"ID Hose)
5	505-0166	2	Tee. Pipe (3/4)	21	503-0398	4	Clamp, Hose
6	505-0332	1	Nipple, Pipe (3/4 x 3)	22		4	Plug. Square Head (3/4")
7	505-0132	ī	Elbow, Pipe (3/4 x 90")	23		1	Hose, LPG (1"ID x 46")
8	505-0102	ě.	Nipple. Close (3/4 x 1-3/8)	24		1	Hose, LPG (1"ID x 43")
9	505-0129	4	Bushing, Reducer (1" x 3/4")	25		1	Brace
10	148 -0626	i	Valve, Adjusting - Load	26	155-1255	1	Clamp, Muffler (1-1/8")
iì	148-0637	วิ	Regulator, LPG (1"NPT)	27	104-0091	2	Nut, Hex (3/8-24)
12	307-0834	2	Valve, Solenoid (3/4"NPT)	28	854-0020	2	Washer, Lock (3/8")
13	148-0601	ī	Regulator, Natural Gas	29			Stud
		_	(1"NPT)	30			Adapter Carburetor
14	502-0390	2	Elbow. Street (90°-3/4)	31			Nut
15	148-0627	1	Switch, Pressure	32			Washer, Flat
16	505-0099	i	Nipple. Pipe (1/4 x .88)	33			Stud
17	505-0020	i	Bushing, Reducer (3/4 x 1/4)				

#### Fuel System LPG Liquid/Natural Gas Automatic Changeover ENA, ENB, ENC



## Fuel System LPG Liquid/Natural Gas Automatic Changeover ENA, ENB, ENC


REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	148-0763	1	Carburetor, Natural Gas	31	505-0099	1	Nipple, Pipe (1/4 x .88)
2	141-0852	1	Gasket, Carburetor	32	502-0943	2	Connector, Hose (5/8"ID Hose)
3	505-0106	1	Nipple, Pipe $(1/2 \times 1-1/2)$	33	503-0547	2	Clamp, Hose
4	505-0021	1	Bushing, Reducer $(3/4 \times 1/2)$	34	503-0386	ī	Hose (5/8"ID x 30")
5	505-0166	2	Tee, Pipe (3/4)	35	503-0386	1	Hose (5/8"ID x 20")
6	505-0332	1	Nipple, Pipe (3/4 x 3)	36	505-0101	ī	Nipple, Close (3/8 x 1")
7	505-0132	1	Elbow, Pipe (3/4 x 90")	37	505-0039	i	Elbow, Pipe (3/8" x 90")
8	505-0102	4	Nipple, Close $(3/4 \times 1-3/8)$	38	505-0132	1	Elbow, Pipe (3/4" x 90")
9	505-0129	4	Bushing, Reducer (1" x 3/4")	39	505-0084	ī	Nipple, Pipe $(3/4 \times 2^{-1/2})$
10	148-0601	i	Regulator, Natural Gas (1"NPT)	40	505-0661	ī	Tee, Reducing (1"x 1" x 3/4")
11	307-0834	1	Valve, Solenoid (3/4 NPT)	41	505-0004	1	Nipple, Close (1" x 1-1/2")
12	148-0626	ī	Valve, Adjusting - Load	42	505-0331	ĩ	Nipple, Pipe (1" × 4")
13	148-0627	ī	Switch, Pressure	43	505-0479	ī	Cap, Pipe (1")
14	505-0099	ī	Nipple, Pipe (1/4 x .88)	44	800-0049	2	Screw, Cap - Hex Head
15	505-0020	<b>1</b>	Bushing, Reducer (3/4 x 1/4)			_	$\{1/4-20 \times 3/4^{\circ}\}$
16	502-0390	2	Elbow, Street (3/4 x 90°)	45	850-0040	2	Washer, Lock (1/4")
17	148-0968	ī	Brace	46	148-0625	1	Convertor, Gas
18	155-1255	ï	Clamp, Muffler (1-1/8")	47	148-0773	ī	Bracket, Convertor
19	821-0016	3	Screw, Self-Locking (5/16-18 x 3/4")	48	800-0069	2	Screw, Cap - Hex Head (7/16-14 x 3/4")
20	502-0971	4	Connector, Hose (1"ID Hose)	49	850-0055	2	Washer, Lock (7/16")
21	503-0398	4	Clamp, Hose	50	148-0776	1	Spacer
22	503-1103	1	Hose (1"ID x 48")	51	800-0051	1	Screw, Cap - Hex Head
23	503-1103	1	Hose (1"ID x 21")				(3/8-16 x 1-1/4")
24	148-0967	1	Bracket, Fuel - Remote	52	850-0050	1	Washer, Lock (3/8")
25	505-0130	1	Plug, Square Head (3/4")	53	854-0020	2	Washer, Lock - Internal
26	505-0054	2	Plug, Square Head (1/4")				Tooth (3/8")
27	505-0020	3	Bushing, Reducer (3/4 x 1/4)	54	104-0091	2	Nut, Hex (3/8-24)
28	501-0608	i	Hose, Fuel - LPG	55	520-0311	2	Stud (3/8-24 x 1-5/8")
			(3/8"ID × 28")	56	145-0482	Ĩ	Adapter, Carburetor
29	505-1463	1	Elbow, Male - 90°	57	110-0445	4	Nut, Hex (5/16-24)
			$(1/4-18 \times 9/16-18)$	58	526-0065	4	Washer, Flat (5/16")
30	307-0268	1	Valve, Solonoid	59	520-0972	4	Stud $(5/16-24 \times 3-1/4")$



#### Fuel System LPG Vapor ENAD

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	148-0966	1	Bracket, Fuel - Remote	6	505-0102	2	Nipple, Pipe (3/4 x 1-3/8)
2	148-0637	1	Regulator, Vapor - LPG	7	505-0130	2	Plug, Square Head (3/4)
3	503-1103	1	Hose, LPG (1"ID x 54")	·=·	505-0132	1	Elbow, Pipe (3/4 x 90°)
4	502-0971	2	Connector, Hose (1"ID Hose)	_	821-0016	2	Screw, Cap - Self-Locking
5	503-0398	2	Clamp, Hose				(5/16-18 × 3/4")


Fuel System Liquid Propane ENAD



#### Fuel System Liquid Propane ENAD


REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	148-0625	1	Converter, Gas	17	502-0971	2	Connector, Hose (1"ID Hose)
2	148-0773	1	Bracket, Converter	18	503-0398	2	Clamp, Hose
3	307-0268	1	Valve, Solenoid	19	503-1103	1	Hose (1"ID x 40")
4	148-0776	1.	Spacer	20	502-0943	2	Connector, Hose (5/8"ID Hose)
5	800-0051	1.	Screw, Cap - Hex Head	21	503-0547	4	Clamp, Hose
			$(3/8-16 \times 1-1/4")$	22	505-0099	1	Nipple, Pipe $(1/4 \times .88)$
6	850-0050	1	Washer, Lock (3/8")	23	505-0101	1	Nipple, Close (3/8 x 1)
7	800-0069	2	Screw, Cap - Hex Head	24	505-0039	1	Elbow, Pipe (3/8 x 90")
			$(7/16-14 \times 3/4")$	25	505-1463	1	Elbow, Male - 90°
8	850-0055	2	Washer, Lock (7/16")				$(1/4 \text{ NPT} \times 9/16-18)$
9	800-0049	2	Screw, Cap - Hex Head	26	503-0386	1	Hose (5/8"ID x 20")
			$(1/4-20 \times 3/4")$	27	503-0386	1	Hose (5/8"ID x 30")
10	850-0040	2	Washer, Lock (1/4")	28	501-0608	1	Hose, Fuel - LPG
11	505-0004	1	Nipple, Close (1" x 1-1/2")				$(3/8"ID \times 28")$
12	505-0661	1	Tee, Reducing	29	148-0966	1	Bracket, Fuel - Remote
			$(1" \times 1" \times 3/4")$	30	505-0020	3	Bushing, Reducer (3/4 x 1/4)
13	505-0331	1	Nipple, Pipe (1" x 4")	31	505-0054	2	Plug, Square Head (1/4)
14	505-0479	1	Cap, Pipe (1")	32	821-0016	2	Screw, Self-Locking
15	505~0084	1	Nipple, Pipe $(3/4 \times 2-1/2)$				$(5/16-18 \times 3/4^n)$
16	505~0132	1	Elbow, Pipe (3/4 x 90°)				

Fuel System Natural Gas/LPG Vapor ENAD



#### Fuel System Natural Gas/LPG Vapor ENAD


REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	148-0637	1	Regulator, LPG (1"NPT)	16	502-0390	2	Elbow, Street (3/4 x 90°)
2	148-0601	1	Regulator, Natural Gas	17	148-0967	1	Bracket, Fuel - Remote
			(Ī"NPT)	18	148-0970	1	Brace
3	307-0834	1	Valve, Solenoid (3/4"NPT)	19	148-0969	1	Brace
4	307-0836	1	Valve, Solenoid (3/4*NPT)	20	503-1103	1	Hose, LPG $(1"ID \times 43")$
5	148-0626	1	Valve, Adjusting - Load	21	503-1103	1	Hose, LPG (1"ID x 46")
6	148-0627	1	Switch, Adjusting - Load	22	503-1103	1	Hose, LPG (1"ID x 5.5")
7	505-0099	1	Nipple, Pipe (1/4 x .88)	23	502-0971	6	Connector, Hose (1"ID Hose)
8	505-0102	5	Nipple, Close $(3/4 \times 1-3/8)$	24	503-0398	6	Clamp, Hose
9	505-0332	1	Nipple, Pipe (3/4 x 3)	25	155-1255	2	Clamp, Muffler (1-1/8")
10	505-0337	1	Nipple, Pipe (3/4 x 4)	26	155-1015	2	Clamp, Muffler (1-1/2")
11	505-0004	1	Nipple, Close $(1 \times 1-1/2)$	27	505-0132	1	Elbow, Pipe (3/4" x 90°)
12	505~0020	1	Bushing, Reducer (3/4 x 1/4)	28	505-0337	1	Nipple, Pipe $(3/4" \times 4")$
13	505-0129	4	Bushing, Reducer (1 x 3/4)	29	505-0130	4	Plug, Square Head (3/4")
14	505-0166	2	Toe, Pipe (3/4)	30	821-0016	4	Screw, Self-Locking
15	505-0132	2	Elbow, Pipe (3/4 × 90')				(5/16-18 × 3/4")



#### Fuel System Natural Gas ENAD, ENBA

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	148-0966	1	Bracket, Fuel - Remote	25	503-1508	2	Clamp, Hose (2")
2	148-0601	1	Regulator, Natural Gas	26			Hose
3	503-1103	1	Hose, LPG (1"ID x 54")		503-1507-01	1	ENAD (2"ID × 3")
4	502-0971	2	Connector, Hose (1"ID Hose)		503-1507-02	1	ENBA $(2"IO \times 4-3/4")$
5	503-0398	2	Clamp, Hose	27	813-0103	4	*Screw, Round Head (#10-32)
6	505-0102	1	Nipple, Close $(3/4 \times 1-1/2")$	28	850-0030	4	*Washer, Lock (#10-32)
7	505-0129	2	Bushing, Reducer $(3/4" \times 1")$	29	526-0008	4	*Washer, Flat (#10-32)
8	505-0130	2	Plug, Square Head (3/4)	30	870-0053	4	*Nut, Hex (#10-32)
9			Elbow	31	145-0540	1	Gasket, Turbocharger
	502-0390	1	ENAD Street (90° x 3/4")	32	145-0629	1	*Adapter, Turbocharger
	505-0132	. 1	ENBA Pipe (3/4" x 90")	33			Body, Throttle
10	821-0016	2	Screw, Self-Locking		145-0538	1	ENAD
			$(5/16-18 \times 3/4")$		145-0577	1	ENBA
11			Turbocharger	34	850-0050	2	Washer, Lock (3/8")
	145-0626	1	ENAD	35	800-0050	2	Screw, Cap - Hex Head
	145-0640	1	ENBA				(3/8-16 × .88")
12			Gasket, Flange - Exhaust	36	141-0852	1	Gasket
	155-2639	1	ENAD	37	145-0482	1	Adapter, Carburetor
	155-2649	1	ENBA	38	520-0011	4	Stud, Steel (5/16-24)
13			Adapter, Exhaust	39	526-0065	4	Washer, Flat (5/16")
	155-2641	1	ENAD	40	110-0445	4	Nut, Head - Cylinder
	155-2647	1	ENBA	_			(5/16-24)
14	850-2008	4	Washer, Lock (M8)	41	862-0003	4	Nut, Hex (3/8-16)
15	800-2058	4	Screw, Cap - Hex Head	42	850-0050	4	Washer, Lock (3/8")
			$(M8 \times 1-1/4 \times 25mm)$	43	145-0533	1	Gasket, Inlet - Turbine
16	505-1369	1	Elbow, Reducer	44	154-2857	1	Tube, Exhaust
17	505-0057	1	Plug, Square Head	45	800-1507	4	Screw, Cap - Hex Head
			(1/8 x 27NPT)				(Grade 8) $(7/16-14 \times 1-1/2")$
18	503-0998	1	Clamp, Hose - T-Bolt (3-1/4")	46	526-0032	4	Washer, Flat (7/16")
19	509-0165	1	"O"-Ring, Inlet	47	800-0574	16	Screw (3/8-16)
20	145-0630	1	Elbow, Inlet	48		-	Manifold, Exhaust
21	145-0532	1	Mixer, Natural Gas		154-2500	1	Left Hand
22	505-0007	1	Bushing, Pipe $(1/4 \times 1/8)$		154-2499	ī	Right Hand
23	140-1260	ī	Fitting, Filler - Safety	49	520-0925	4	Stud $(3/8-16 \times 1-1/4)$
24		_	Indicator, Service	50			Washer, Lock (5/16")
	140-1791	1	ENAD	51	800-0029		Screw, Cap - Hex Head
	140-1548	ī	ENBA				$(5/16-18 \times 1-1/8")$


Fuel System
ral Gas/LPG Liquid
stomatic Changeover
ENAD -23 -19 21 -22 24 -19 -13 25 19 16 10 -36 27 46 38 20 45 19 30 14 49 28-47. OF. 25 -40 20. 20



# Fuel System Natural Gas/LPG Liquid Dual Automatic Changeover ENAD


REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	148-0601	1	Regulator, Natural Gas (1"NPT)	30	505-1463	1	Elbow, Male - 90° (1/4-18" NPT x 9/16-18")
2	307-0836	1	Valve, Solenoid (3/4"NPT)	31	505-0020	3	Bushing, Reducer $(3/4 \times 1/4)$
3	148-0626	ĩ	Valve, Adjusting - Load	32	505-0054	2	Plug, Square Head (1/4)
4	148-0627	1	Switch, Pressure	33	505-0130	2	Plug, Square Head (3/4)
5	505-0099	ĭ	Nipple, Pipe $(1/4 \times .88)$	34	148-0967	1	Bracket, Fuel - Remote
6	505-0102	3	Nipple, Close $(3/4 \times 1-3/8)$	35	148-0776	1	Spacer
7	505-0332	1	Nipple, Pipe $(3/4 \times 3)$	36	800-0051	1	Screw, Cap - Hex Head
8	505-0337	ĩ	Nipple, Pipe $(3/4 \times 4)$				$(3/8-16 \times 1-1/4")$
9	505-0004	ī	Nipple, Close $(1 \times 1-1/2)$	37	850-0050	1	Washer, Lock (3/8")
10	505-0020	ĩ	Bushing, Reducer (3/4 x 1/4)	38	148-0773	1	Bracket
11	505-0129	4	Bushing, Reducer (1 x 3/4)	39	800-0069	2	Screw, Cap - Hex Head
12	505-0166	2	Tee, Pipe (3/4)				$(7/16-14 \times 3/4")$
13	505-0132	2	Elbow, Pipe (3/4 x 90°)	40	850-0055	2	Washer, Lock (7/16")
14	502-0390	2	Elbow, Street (3/4 x 90°)	41	148-0625	1	Converter, Gas
15	148-0970	1	Brace	42	800-0049	2	Screw, Cap - Hex Head
16	149-0969	i	Brace				$(1/4-20 \times 3/4")$
17	155-1255	ï	Clamp, Muffler (1-1/8")	43	850-0040	2	Washer, Lock (1/4")
18	155-1015	1	Clamp, Muffler (1-1/2")	44	505-0101	1	Nipple, Close (3/8 x 1)
19	502-0971	6	Connector, Hose (1"ID Hose)	45	505-0039	1	Elbow, Pipe (3/8 × 90")
20	503-0398	6	Clamp, Hose	46	502-0943	2	Connector, Hose (5/8"ID Hose)
21	503-1103	1	Hose, LPG (1"ID x 5.5")	47	503-0547	2	Clamp, Hose
22	821-0016	4	Screw, Self-Locking	48	505-0099	1	Nipple, Close $(1/4 \times .88)$
·			$(5/16-18 \times 3/4")$	49	307-0268	1	Valve, Solenoid
23	505-0132	2	Elbow, Pipe (3/8" x 90")	50	505-0004	1	Nipple, Close $(1" \times 1-1/2")$
24	505-0037	1	Nipple, Pipe (3/4" x 4")	51	505-0661	1	Tee, Reducer $(1" \times 1" \times 3/4")$
25	503-1103	1	Hose, LPG (1"ID x 21")	52	505-0331	1	Nipple, Pipe (1" × 4")
26	503-1103	1	Hose, LPG (1"ID x 46")	53	505-0479	1	Cap, Pipe (1")
27	503-0386	1	Hose (5/8"ID x 30")	54	505-0084	1	Nipple, Pipe $(3/4 \times 2-1/2)$
28	503-0386	1	Hose (5/8"ID x 20")				
29	501-0608	i	Hose, Fuel - LPG (3/8"ID × 28")				

Air Cleaner ENA, ENB, ENC




REF	PART	QTY	PART	REF	PART	QTY	PART
NO.	NO.	USED	DESCRIPTION	NO.	NO.	USED	DESCRIPTION
1 2	140-1083 140-1089	1 1	Cleaner Assembly, Air Element, Cleaner - Air				

Air Cleaner ENAD, ENBA




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF No.	PART NO.	QTY USED	PART DESCRIPTION
1	140-1724	1	Cleaner Assembly, Air	6	503-1506	1	Hose, Bulk (12")
2	140-1837	1	Element, Cleaner - Air	7	502-1012	1	Connector, Hose
3	503-0547	2	Clamp, Hose	8	505-0011	1	Elbow, Pipe - Street
4	503-1093	1	Hose				$(1/4 \times 90^{\circ})$
5	503~0446	2	Clamp, Hose	9	505-0017	1	Bushing, Reducer $(3/8 \times 1/4)$

Air Cleaner With Preheat ENA, ENB, ENC




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	140-1400	1	Cleaner Assembly, Air	5	870-0212	4	Nut, Lock (1/4-20)
_	140-1089	1	Element, Cleaner - Air	6	503-0365	2	Clamp, Hose
2	140-1401	ī	Retainer, Heater Duct - Carburetor	7	140-1402	1	Jacket, Air Heater - Carburetor
3	140-1431	1	Inlet, Cleaner - Air	8	503-0082	1	Hose (2"ID × 10")
4	821-0008	2	Screw, Hex Head - Self-Locking (1/4-20 x .31")	9	821-0011	2	Screw, Self-Locking (1/4-20 x .88")

Dry Exhaust Manifold




REF NO.	PART NO.	QTY USED	PART Description	REF NO.	PART NO.	QTY USED	PART DESCRIPTION	
1	800-0574	16	Screw, Hex Head - Self-Locking (3/8-16 × 1-3/8")	5 6	526-0032 154-2500	4 1	Washer, Flat (7/16") Manifold, Exhaust Left Side	
2	155-1395	2	Gasket		154-2499	ī	Right Side	
3	155-2214	1	Tube, Exhaust					
4	800-0598	4	Screw, Cap - Hex Head (7/16-14 > 1-1/2") (Grade 8					

Muffler ENA, ENB, ENC




REF NO.	PART NO.	QTY USED	PART Description	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	155-0989	1	Muffler	6	870-0117	4	Nut, Self-Locking (7/16-14)
2	140-0757	2	Clamp	7	526-0032	4	Washer, Flat (7/16")
3	155-0997	1	Shield, Heat - Muffler	8	155-2218	1	Tube, Exhaust
4	155-1430	4	Spacer	9	155-2105	1	Clamp, Muffler
5	800-0078	4	Screw, Cap - Hex Head (7/16-14 x 2-3/4")	10	505-0387	1	Nipple, Half

Exhaust Muffler ENAD, ENBA




REF NO.	PART NO.	QTY USED	PART Description	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	155-2105	1	Clamp	7	870-0133	4	Nut, Hex (3/8-16)
2	155-2638	1	Tube, Exhaust	8	155-1430	4	Spacer
3	505-0387	1	Nipple, Pipe - Half	9	155-2198	2	Band, Mounting
4	155-2062-07	1	Cap, Rain	10	155-2197	1	Shield, Heat
5	155 <b>-</b> 21 <b>9</b> 6-01	1	Muffler, Exhaust	11	526-0029	4	Washer, Flat (3/8")
6	800-0057	4	Screw, Cap - Hex Head (3/8-16 x 2-3/4")				



#### Lube Oil System

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	122-0193	1	Filter, Oil	17	503-0547	2	Clamp, Hose
2	503-0446	4	Clamp, Hose	18	503-1097	1	Hose, Rubber (5/8"ID × 34")
3	503-1099	1	Hose, Rubber $(1/2"ID \times 29")$	19	505-0135	2	Nipple, Pipe - Half
4	502-1168	2	Connector, Hose	20	800-0026	2	Screw, Cap - Hex Head
5	505-0019	2	Bushing, Reducer				(5/16-18 × 3/4")
			(1/2NPT × 3/8)	21	850-0045	2	Washer, Lock - Spring (5/16")
6	821-0018	2	Screw, Hex Washer Head -	22	121-0036	1	Plate, Return - Oil
			Self-Locking $(1/4-20 \times .62^n)$	23	800-0050	2	Screw, Cap - Hex Head
7	503-1100	1	Hose (1/2"ID x 23")				$(3/8-16 \times 7/8^{\text{N}})$
8	102-1098	1	Cooler, Oil	24	850-0050	2	Washer, Lock - Spring (3/8")
9	102~1097	1	Adapter Unit (Includes "O"	25	145-0534	1	Flange, Drain - Oil
			Ring, Housing w/Thermostat	26	145-0535	1	Gasket
			and Female/Male Hex Adapter)	27	127-0423	1	Line, Inlet - Oil
10	503-0547	2	Clamp, Hose	28	502-1169	1	Connector, Female
11	503-0966	1	Hose, Rubber (5/8"ID x 30")				$(M12 \times 5/8-18)$
12	505-0135	2	Nipple, Pipe - Half	29	509-0290-04	1	Seal, "O"Ring
			$(3/8"NPT \times 1-1/2)$	30	502-0003	1	Conector, Male - Inverted
13	504-0030	1	Valve, Cock (3/8"NPT)	31	505-0039	1	Elbow, Pipe (3/8"NPT x 90")
14	502-1013	1	Adapter, Pipe - Hex	32	505-0277	1	Nipple, Pipe (3/8 x 1-1/2)
15	102-1320	1	Gasket, Drain - Oil	33	505-0131	1	Bushing, Pipe $(3/4 \times 3/8)$
16	123-1900	1	Tube, Indicator - Oil Level	34	123-1901	1	Indicator, Level - Oil


Radiator Cooling System ENA, ENB, ENC, ENAD



## Radiator Cooling System ENA, ENB, ENC, ENAD

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QT? USED	PART DESCRIPTION
1	821-0029	17	Screw, Cap - Hex Head	20	850-0060	1	Washer, Lock (1/2")
			(3/8-16 × 3/4")	21	526-0035	1	Washer, Flat (1/2")
2	870-0281	17	Nut, Hex (3/8-16)	22	862-0016	1	Nut, Hex (1/2-13)
3			Guard, Radiator - Right Hand	23	130-4058	1	Brace, Drive - Fan
	130-3038-01	1	ENA, ENB, ENC	24			Hose, Radiator - Lower
	130-4047-01	1	ENAD		503-1558	1	ENA, ENB, ENC
4			Guard, Radiator - Laft Hand		130-1999	1	ENAD
	130-3038-02	1	ENA, ENB. ENC	25	130-3967	1	Bracket, Drive - Fan
_	130-4047-02	1	ENAD	26	850-0050	5	Washer, Lock (3/8")
5			Support, Grille	27	800-0051	2	Screw, Cap - Hex Head
	130-3039	1	ENA, ENB, ENC		441 444		(3/8-16 × 1-1/4")
	130-4049	1	ENAD	28	191-0864	1	Spacer Com Nov. Hand
6	821-0018	51	Screw, Cap - Hex Head {1/4-20 x 5/8"}	29	<b>e00-0050</b>	2	Screw, Gap - Hex Head (3/8-16 x 1")
7			Fan, Radiator	30	130-4056	1	Guard, Belt
	130-0428	1	ENA, ENB, ENC	31	800-0055	4	Screw, Cap - Hex Head
	130-1997	1	ENAD				$(3/8-16 \times 2-1/4")$
8	800-0028	4	Screw, Cap - Hex Head	32	130-0968	1	Adapter, Pulley
			(5/16-18 × 1")	33	104-1673	1	Pulley, Crankshaft (6"0D)
9	850-0045	4	Washer, Lock (5/16")	34	800-0023	4	Screw, Cap - Hex Head
10	511-0153	1	Belt, Vee (Matched Set)				$(1/4-20 \times 1-3/8")$
11		_	Grille	35	850-0040	4	Washer, Lock (1/4")
	130-3088	1	ENA, ENB, ENC	36	504~0003	1	Cock, Drain (1/4-18NPT)
	130-4050	1	ENAD	37	100 0100		Shroud, Fan
12			Support, Grille		130-3138	2	ENA, ENB, ENC
	130-3037	1	ENA. ENB, ENC	20	130-4052	2	ENAD
••	130-4048	1	ENAD	38	120 2144	1	Radiator
13		1	Guard, Fan		130-3144 130-3567	i	ENA, ENB, ENC ENAD
14	130-2983	1	Hub & Pulley Assembly	20	130-3367	i	Guard, Belt
	130-0972	1	Collar, Hub - Fan		130-4057	1	Guard, Belt
	518-0348	2	Ring, Retaining - Internal Screw, Hex - Self-Locking	41	130-4054	i	Bracket, Guard - 8elt
	821-0011		$(1/4-20 \times 7/8")$	42	_	-	Wrapper, Shroud
	512-0170	1	Pulley, Fan (5"00)		130-4061	1	ENA, ENB, ENC
	130-0970	1	Bearing, Hub - Fan		130-4052	1	ENAD
16	130-0969	1	Hub, Drive - Fan Tube, Inlet - Radiator	43	821-0028	16	Screw, Cap - Hex Head (3/8-16 x 1/2")
	130-3041	1	ENA, ENB, ENC	44	130-1788	1	Cap, Radiator
	130-4059	1	ENAD	45	800-0052	1	Screw, Cap - Hex Head
17	503-0365	6	Clamp, Hose				$(3/8-16 \times 1-1/2")$
18	503-1554	2	Hose, Radiator	46	526-0030	1	Washer, Flat (3/8")
19	821-0016	2	Screw, Hex Head - Self-Locking (5/16-18 x 3/4")	47	130-4060	1	Guard, Belt

### Radiator Cooling System ENBA




# Radiator Cooling System ENBA


REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	821-0029	17	Screw, Cap - Hex Head	20	850-0060	1	Washer, Lock - Spring (1/2)
			(3/8-16 × 3/4")	21	526-0035	1	Washer, Flat (1/2)
2	870-0281	17	Nut, Self-Locking - Hex	22	862-0016	1	Nut, Hex (1/2-13)
			Washer Head (3/8-16)	23	130-4058	1	Brace, Bracket - Fan Drive
3	130-4047-01	1	Guard, Radiator (Right Hand)		130-1999	1	Hose, Radiator - Lower
4	130-4047-02	1	Guard, Radiator (Left Hand)	25	130-3967	1	Bracket, Drive - Fan
5	130-4049	1	Support, Grille	26	850-0050	3	Washer, Lock - Spring (3/8)
6	821-0018	42	Screw, Cap - Hex Head (1/4-20 x 5/8")	27	800-0051	1	Screw, Cap - Hex Head (3/8-16 x 1-1/4")
7	130-1997	1	Fan, Radiator	29	800-0050	1	Screw, Cap - Hex Head
8	800-0028	4	Screw. Cap - Hex Head				$(3/8-16 \times 1^{*})$
			(5/16-18 × 1")	31	800-0055	4	Screw, Cap - Hex Head
9	850-0045	4	Washer, Lock - Spring (5/16)				$(3/8-16 \times 2-1/4^{\circ})$
10	511-0153	1	Belt, Vee (Matched Set)	32	130-0968	1	Adapter, Pulley
11	130-4050	1	Grille Assembly	33	104-1673	1	Pulley, Crankshaft (6" O.D.)
12	130-4048	1	Support, Grille	34	800-0023	4	Screw, Cap - Hex Head
13	130-4055	1	Guard, Fan				$(1/4-20 \times 1-3/8")$
15	130-2983	1	Hub and Pulley Assembly	35	850-0040	4	Washer, Lock - Spring (1/4)
			(Includes the following non-	36	504-0003	1	Cock, Drain (1/4-18 NPT)
			illustrated parts marked *)	37	130-4052	2	Shroud, Fan
	130-0972	1	*Collar, Hub - Fan	38	130-3567	1	Radiator
	518-0348	2	*Ring, Retaining - Internal	39	130-4053	1	Guard, Belt
	821-0011	4	*Screw, Self-Locking - Hex		130-4057	1	Guard, Belt
			Washer Head (1/4-20 x 7/8")	41	130-4065	1	Bracket, Guard - Belt
	512-0170	1	*Pulley, Fan (5" O.D.)	42	130-4051	1	Wrapper, Shroud - Fan
	130-0970	1	*Bearing, Hub - Fan	43	821-0028	16	Screw, Cap - Hex Head
	130-0969	1	*Hub, Drive - Fan				(3/8-16 × 1/2")
16	130-4059	1	Tube, Inlet - Upper Radiator	44	130-1788	1	Cap, Radiator
17	503-0365	8	Clamp, Hose	45	800-0052	1	Screw, Cap - Hex head
18	503-1554	4	Hose				(3/8-16 x 1-1/2)
19	821-0016	2	Screw, Self-Locking - Hex	46	526-0030	1	Washer, Flat (3/8)
			Washer Head (5/16-18 × 3/4")	47	130-4062	1	Guard, Belt

<sup>\* -</sup> Parts included with Hub and Pulley Assembly.

Remote Radiator ENA, ENB, ENC




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	130-3056	1	Guard, Belt	7	850-0051	1	Screw, Cap - Hex Head
2	130-3057	1	Cover, Guard - Belt				(3/8-16 × 1-1/4")
3	130-3053	1	Guard, Belt	8	191-0864	1	Spacer
4	821-0010	26	Screw, Cap - Hex Head	9	130-3055	1	Guard, Belt
			$(1/4-20 \times 1/2")$	10	130-3054	1	Guard, Belt
5	800-0050	1	Screw, Cap - Hex Head	11	130-3003	1	Bracket, Guard - Belt
_		_	$(3/8-16 \times 1")$	12	130-3002	1	Bracket, Guard - Belt
6	850-0050	2	Washer, Lock - Spring (3/8")				



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	130-1050	1	Guard, Belt	14	800-0051	1	Screw, Hex Head - Self-Locking
2	130-1008	1	Strap, Guard - Belt				$(3/8-16 \times 1-1/4")$
3	130-1009	1	Spacer, Guard - Belt	15	800-0056	1	Screw, Hex Head - Self-Locking
4	102-1244	2	Bracket, Cooler - Oil				$(3/8-16 \times 2-1/2")$
5	102-1097	1	Adapter, Cooler - Oil	16	800-0069	1	Screw, Hex Head - Self-Locking
6	102-1238	1	Cooler, Oil				$(7/16-14 \times 3/4")$
7	503-0753	1	Hose, Radiator - Flex	17	870-0212	1	Nut, Hex (1/4-20)
8	503-1101	1	Hose, Oil (12")	18	870-0281	2	Nut, Hex (3/8-16)
9	503-1101	1	Hose, Oil (24")	19	850-0050	2	Washer, Lock (3/8")
10	503-0274	2	Clamp, Hose	20	850-0055	1	Washer, Lock (7/16)
11	503-0446	4	Clamp, Hose	21	526-0174	2	Washer, Flat (3/8")
12	821-0011	1	Screw, Hex Head - Self-Locking	22	505-0018	2	Bushing, Reducer (1/8 x 1/4)
			(1/4-20 x .88")	23	505-0302	2	Nipple, Half $(1/4 \times 1-1/2)$
13	821-0029	6	Screw, Hex Head - Self-Locking (3/8-16 x 3/4")				.,


Cooling System Heat Exchanger ENAD



#### Cooling System Heat Exchanger ENAD


REF No.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	503-0274	4	Clamp, Hose	23	130-0802	2	Strap, Holddown
2	503-0846	1	Hose, Rubber - Lower	24	130-1112	1	Strap, Support
			(2"ID × 20")	25	102-1159	1	Support, Cooler - Oil
3	503-0753	1	Hose, Rubber - Upper	26	130-1340	1	Pencil, Zinc (3/8"NPT)
			$(2"ID \times 24")$	27	130-2162	1	Exchanger, Head (Includes
4	503-0446	4	Clamp, Hose				Cap)
5	503-1099	2	Hose, Rubber $(1/2"ID \times 29")$	28	130-0661	1	Cap, Exchanger - Heat (7 PSI)
6	505-0302	2	Nipple, Pipe - Half	29	821-0016	3	Screw, Hex Washer Head -
			$(1/4"NPT \times 1-1/2")$				Self-Locking
7	505-0038	2	Elbow, Pipe - 90' (1/4"NPT)				$(5/16-18 \times 3/4")$
8	505-0099	2	Nipple, Pipe - Close		130-1110	1	Bracket, Mounting
			$(1/4"NPT \times 7/8")$	31	130-3151	1	Bracket, Mounting - Heat
9	505-0018	2	Bushing, Reducer - Hex			_	Exchanger
			$(1/2"NPT \times 1/4"NPT)$	32	800-0069	1	Screw. Cap - Hex Head
10	505-0102	6	Nipple, Pipe			_	$(7/16-14 \times 3/4")$
		_	$(3/4"NPT \times 1-3/8")$		850-0055	1	Washer, Lock - Spring (7/16")
11	307-0835	1	Valve, Solenoid - 12VDC	34	130-1008	1	Strap
12	505-0132	2	Elbow, Pipe - 90° (3/4"NPT)	35	800-0056	1	Screw, Cap - Hex Head
13	102-1114	1	Cooler, Oil		000 0051		(3/8-16 × 2-1/2")
14	505-0130	2	Plug, Pipe (3/4"NPT)	36	800-0051	1	Screw, Cap - Hex Head
15	505-1301	1	Valve, Control - Temperature	~#	050 0050	•	$(3/8-16 \times 1-1/4")$
	505 0100		Regulating (1"NPT)	37	850-0050	2	Washer, Lock - Spring (3/8")
16	505-0129	1	Bushing, Reducer - Hex	38	526-0174	2 1	Washer, Flat (3/8")
10	505 00F1	- 4	(1"NPT x 3/4"NPT)	39	130-1009	1	Spacer, Sleeve
17	505-0051	1	Elbow, Pipe - Street (90*)	4.7	130-1050	1	Guard, Belt
10	FOF 0305		(3/4"NPT)	41 42	504-0046	1	Valve, Globe (3/4"NPT)
18	505-0385	1	Nipple, Pipe - Half	42	148-0274	2	Bracket, "J"
10	505-0043		(1-1/2"NPT x 2") Elbow, Pipe - 90* (1-1/2"NPT)	43	821-0029	4	Screw, Hex Head -
19 20	505-0043	1 1		44	021-0029		Self-Locking (3/8-16 × 3/4")
20	202-0108		Nipple, Pipe (1-1/2"NPT x 2-1/5")	45	870-0281	4	Nut, Lock (3/8-16)
21	821-0011	7	Screw, Hex Washer Head -	46	505-0140	i	Plug, Square Head (1")
21	621-0011	,	Self-Locking $(1/4-20 \times 7/8")$	40	303 0140	•	1 10g, 0400/0 11000 (1 )
22	870-0212	7	Nut, Hex Washer Head - Self- Locking (1/4-20)				

Cooling System Heat Exchanger ENBA




#### Cooling System Heat Exchanger ENBA

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	503-0274	2	Clamp, Hose	16	821-0011	6	Screw, Hex Washer Head -
2	503-0753	2	Hose, Rubber				Self-Locking $(1/4-20 \times 7/8")$
3	503-0446	4	Clamp, Hose	17	870-0212	6	Nut, Hex Washer Head - Self-
4	503-1101	2	Hose, Oil				Locking (1/4-20)
5	505-0302	2	Nipple, Pipe - Half	18	130-0802	2	Strap, Holddown
			(1/4"NPT x 1-1/2")	19	130-1112	1	Strap, Support
6	505-0038	2	Elbow, Pipe - 90* (1/4"NPT)	20	102-1159	1	Support, Cooler - Oil
7	505-0099	2	Nipple, Pipe - Close	21	130-1340	1	Pencil, Zinc (3/8"NPT)
		-	(1/4"NPT x 7/8")	22	130-2162	1	Exchanger, Head (Includes
8	505-0018	2	Bushing, Reducer - Hex				Cap)
•		-	(1/2"NPT x 1/4"NPT)	23	130-0661	1	Cap, Exchanger - Heat (7 PSI)
9	505-0102	6	Nipple, Pipe	24	821-0010	8	Screw, Hex Washer Head -
•	000 0101	•	(3/4"NPT x 1-3/8")	_			Self-Locking (5/16-18 x 3/4")
10	307-0835	1	Valve, Solenoid - 12VDC	25	130-1110	1	Bracket, Mounting
îĭ	505-0132	2	Elbow, Pipe - 90" (3/4"NPT)	26	130-3151	ī	Bracket, Mounting
12	102-1114	ī	Cooler, Oil	27	821-0029	5	Screw, Hex Head -
13	505-0385	i	Nipple, Pipe - Half		<b>V</b>	•	Self-Locking (3/8-16 x 3/4")
10	000 0000	-	(1-1/2"NPT x 2")	28	870-0281	4	Nut, Lock (3/8-16)
14	505-0043	1	Elbow, Pipe - 90" (1-1/2"NPT)	29	503-1101	ì	Hose, Oil (18")
15	505-0109	1	Nipple, Pipe	30	309-0241	ī	Valve, Temperature - Water
13	202 0103	1	(1-1/5"NPT × 2-1/5")	31	505-0029	î	Coupling (3/4")



#### Water Heater


REF NO.	PART NO.	QTY USED	PART DESCRIPTION	ref No.	PART NO.	QTY USED	PART DESCRIPTION
1	503-0183	4	Clamp, Hose	15	526-0018	4	Washer, Flat (1/4")
2	503~0386	_	Hose, Bulk (3 Ft Required)	16	850-0040	4	Washer, Lock - Spring (1/4")
3	503-0386	_	Hose, Bulk (1 Ft Required)	17	862-0001	4	Nut, Hex (1/4-20)
4	502-0613	2	Connector, Hose	18	504-0003	1	Cock, Drain
5	502-0156	2	Elbow, Pipe - Street, 45 DEG	19			Heater, Electrical - 2000 Wat
6	502-0942	2	Connector, Hose - 90 DEG		333~0158	1	115 VAC, 1 Phase
7	505-0455	2	Bushing, Reducer - Hex		333-0167	1	208 VAC, 1 Phase
8	331-0027	2	Clamp, Cable		333-0141	1	230 VAC, 1 Phase
9	309-0304	ī	Switch, Thermostatic		333-0147	1	480 VAC, 1 Phase
10	505-0004	1	Nipple, Pipe - Close		333-0148	1	208 VAC, 3 Phase
11	330-0004	ī	Cover		333-0146	1	440 VAC, 3 Phase
12	330-0005	ī	Вох		333-0146	1	480 VAC, 3 Phase
	812-0100	2	Screw, Machine - Round Head (#10-24 x 1/2")	20	821-0029	4	Screw, Self-locking - Hex Washer Head (3/8-16 x 3/4")
	850-0030	2	Washer, Lock - Spring (#10)	21	130-2851	1	Bracket, Mounting
	860-0011	2	Nut, Hex (\$10-24)	22	130-2850	1	Plate, Mounting
13		ī	Contactor				Terminals (Not Illustrated)
	812-0100	2	Screw, Machine - Round Head		332~0014	2	Terminal - #10
		_	(#10-24 x 1/2")		332-0149	5	Terminal - #8
	850-0030	2	Washer, Lock - Spring (#10)		323-0957	2	Nut, Wire
	860-0011	2	Nut, Hex (#10-24)				
14	800-0006	4	Screw, Cap - Hex Head (1/4-20 x 3/4")				



#### Set Housing

REF NO.		QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Top, Housing	16			Post, Housing - Center (RH)
	405-4577	1	ENA, ENB, ENC		405-4575-01	1	ENA, ENB, ENC
	405-4569	ī	ENAD, ENBA		405-4567-02	ī	ENAD, ENBA
2	405-3950	2	Door, Housing - Side	17	405-4566	2	Door, Housing with Grille
3	405-3984	ī	Door, Access - Right Side	18		2	Door, Housing with Grille
_		-	(Includes Door Clips)		405-3980	2	Stop, Door
4	405-3985	1	Door, Access - Left Side (Includes Door Clips)	20	815-0236	4	Screw, Hex Head - Thd Forming (5/16-18 x .62")
5	405-3859-01	1	Post, Housing - Rear (RH)	21	819-1102	10	Screw, Pan Head - Cross-Rec
6	405-3859-02	ī	Post, Housing - Rear (LH)				$(5/16-18 \times 1/2")$
7	405-3833	ī	Grille	22	128-0158	6	Insulation, Foam
8	405-3828	ī	Panel, Housing - Rear	23	128-0110	2	Insulation, Foam
9	405-3952	ī	Door, Control	24	517-0061	4	Plug, Plastic
10	819-1083	15	Screw, Pan Head	25	818-0150	8	Rivet, Drive
			$(1/4-20 \times 7/16")$	26	526-0003	8	Washer, Flat
11	821-0029	22	Screw, Self-Locking	27	405-1872	4	Clip, Door
			$(3/8-16 \times 3/4")$	28	98-5429	2	Decal, "Coolant Fill"
12	870-0281	18	Nut, Hex - Self-Locking	29	406-0626	7	Handle, Door (Includes Key)
			(3/8-16)	30	406-0639	1	Key, Handle - Door
13	821-0014	8	Screw, Hex Head - Self-Locking (5/16-18 x 1/2")	31	815-0607	28	Screw, Machine - Oval Head (#8-32 x 3/8")
14	870-0257	4	Nut, Hex - Self-Locking (5/16-18)	32	870-0235	28	Nut, Hex - Self-Locking (#8-32)
15			Post, Housing - Center (LH)	33	517-0138-09	1	Plug
	405-4575-02	1	ENA, ENB, ENC				•
	405-4567-01	1	ENAD ENRA				


#### Chassis



### Chassis


REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	800-0048	1	Screw, Cap - Hex Head	21	526-0238	2	Washer, Flat (3/4")
			(3/8-16 × 3/4")	22	862-0008	2	Nut, Hex (3/4-10)
2	416-0984	1	Bracket, Battery	23	403-2505-01	1	Bracket, Mounting - Engine
6	800-0071	6	Screw, Cap - Hex Head				Right Side
			$(7/16-14 \times 1")$	24	403-2505-02	1	Bracket, Mounting - Engine
7	850-0055	6	Washer, Lock - Spring (7/16")				Left Side (Not Illustrated)
8	856-0013	6	Washer, Lock - EIT (7/16")	25	800-0026	3	Screw, Cap - Hex Head
9	800-0071	4	Screw, Cap - Hex Head				$(5/16-18 \times 3/4")$
			$(7/16-14 \times 1")$	26	856-0008	1	Washer, Lock - EIT (5/16")
10	526-0219	4	Washer, Flat (7/16")	27	850-0045	1	Washer, Lock - Spring (5/16")
11	850-0055	5	Washer, Lock - Spring (7/16")	28	870-0257	1	Nut, Self-locking - Hex
12	862-0004	4	Nut, Hex (7/16-14)				Washer Head (5/16-18)
13	800-0090	4	Screw, Cap - Hex Head	29	332-1473	1	Terminal, Lug - Ground
			$(1/2-13 \times 1")$	30			Skid
14	B50-0060	4	Washer, Lock - Spring (1/2")		403-3329	1	ENA, ENB, ENC
15	856-0013	2	Washer, Lock - EIT (1/2")		403-3318	1	ENAD, ENBA
16	337-0090	1	Strap, Electrical - Ground	31	870-0196	1	Nut Insulation
17	402-0371	4	Mount, Vibration	32	821-0018	5	Screw, Lockhead
18	800-0520	2	Screw, Cap - Hex Head				(1/4-20 x 5/8")
			$(3/4-10 \times 1")$	33	166-0773	1	Bracket, Ignition Module
19	850~0079	4	Washer, Lock - Spring (3/4")				
20	800-0153	2	Screw, Cap - Hex Head				
		-	(3/4-10 × 1-1/2")				

#### Low Coolant Level




REF MO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	338-1919	1	Harness, Wiring - Low Coolant Level				
2	193-0322	1	Sender, Low Coolant				

### Control Housing




REF	PART NO.	QTY USED	PART DESCRIPTION	REF	PART NO.	QTY USED	PART DESCRIPTION
NO.	MV.	USEU	DEGUNIF 1 TOR			****	
1			Box, Mounting - Control	10			Washer, Lock-Spring
	319-1189	1	UC22 Generator		850-2010	6	M10 (UC22 Generator)
	319-1193	ī	UC27 Generator		850-2012	6	M12 (UC27 Generator)
2	301-3156	3	Panel, Box - Control Mounting	11			Washer, Flat
3	508-0051	1	Grommet		526-2120	8	M10 (UC22 Generator)
4	815-0350	18	Screw, Hex Head - Slotted		526-2140	8	M12 (UC27 Generator)
•	•••		$(#10-32 \times .38")$	12	860-2009	8	Nut, Hex (M10 x 1.5)
5	821-C018	1	Screw, Cap - Locking Head	13	850-2010	8	Washer, Lock - Spring (M10)
-		_	$(1/4-20 \times .62")$	14	526-2120	8	Washer, Flat (M10)
6	526-0018	1	Washer, Flat (1/4)	15	332-2987	4	Link, Terminal
7	856-0006	ĩ	Washer, Lock - EIT (1/4)	16	332-3107	1	Block, Terminal
8	821-0014	4	Screw, Cap - Locking Head	17	338-2506	1	Harness, Wiring
_			$(5/16-18 \times 1/2")$	18	812-0085	3	Screw, Machine - Round Head
9			Screw, Cap-Hex head				(#8-32 × 1-1/8")
-	800-2088	6	M10 x 1.5 x 35mm (UC22	19	850-0025	3	Washer, Lock - Spring (#8)
		_	Generator	20	870-0221	3	Nut, Hex - Machine (#8-32)
	800-2112	6	$M12 \times 1.75 \times 30mm$ (UC27	21	232-3536	1	Base, Block - Terminal
		_	Generator	22	332-1445	4	Tie, Cable



#### Control


REF No.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
4	508-0051	1	Grommet (2" Hole)	28	815-0540	4	Screw, Machine - Round Head -
5	301-8065	1	Box, Control		010 0040	~	Cross Recessed with IT
6	402-0527	4	Isolator, Vibration				(#8-32 x 1")
7	800-0045	4	Screw, Cap - Hex Head (5/16-18 x 3/8")	29	300-2856	1	Board, Printed Circuit -
8	850-0045	4	Washer, Lock - Spring (5/16")	30	812-0063	8	Alarm Relay (A14) Screw, Machine - Round Head
9	508-0001	ĩ	Grommet (1-1/16" Hole)	30	812-0003		
10	406-0332	2		2.1	053.0003		(#6-32 x 1/2")
11	406-0333	2	Receptable, Fastener	31	853-0003	8	Washer, Lock - ET (#6)
12			Stud, Fastener	32	300-2863	1	Board, Printed Circuit -
	406-0334	2	Washer, Retainer - Stud				Alarm Relay (A13)
13	332-0052	2	Clip, Wire	33	8150544	4	Screw, Machine - Round Head -
14	870-0131	6	Nut, Hex - With ET (#10-32)				Cross Recessed with IT
15	871-0015	1	Nut. Hex (1/4-20) Grounding				(#6-32 × 1/2")
			Stud	34	301-8851	1	Bracket, Mounting
16	853-0013	1	Washer, Lock - ET (1/4")	35	338 2277	1	Harness, Wiring - DC
			Grounding Stud				(Includes Connector Housing
17	337-0049	1	Strap, Ground				and Contact Pins) (DC Door
18	800-0024	ī	Screw, Cap - Hex Head				Assembly to Engine Monitor)
-	****	•	(5/16-18 × 1/2")	36	323-1308	1	
19	856-0008	1	Washer, Lock - EIT (5/16")	30	323 1300	1	Housing, Connector - 12 Place (J4)
20	821-0004	ė	Screw, Self-Locking - Hex	27	202-1200	* ^	, ,
20	021 0004	0		37	323-1302	12	Pin, Contact
21	332-0607	1	Washer Head (#10-32 x 5/16") Block. Terminal - 12 Place	38 300-28 300-28	809 1 7 Light Co	ntrol 12 Vo	Monitor, Engine (Includes oltsFuses) (A11) olts 7 Light Control 24 Volts
23	332-2723	1	(TB21)		300-2810		
22		1	Strip, Marker - 12 Place		300-2812	1	12 Light Control24 Volts
23	812-0065	2	Screw, Machine - Round Head	39			Fuse
			(#6-32 x 5/8")		321-0270	2	20 Amp (F1,F2)
24			Harness, Wiring		321-0231	1	15 Amp (F3)
	338-2278	1	AC Door Assembly to TB21		321~0094	2	5 Amp (F4,F5)
			Terminal Block (Includes TB21 Terminal Block)	40	-	1	Door Assembly, Control - AC (See Separate Page for
	338-1835	1	Alarm Relay (8 Wire) (A13			_	Components)
	222 1222		to AllTB1 and TB2)	41	-	1	Door Assembly, Control - DC
	338-1836	1	Alarm Relay (5 Wire) (A14 to A11TB2)				(See Separate Page for Components)
25			Board, Voltage Regulator	42			Harness, Wiring - Engine to
			(VR21) (Also Available from				Control (Includes Grommet,
	,		Newage as Part Number				Resistor, Rectifier, Diode,
			E000-24030)				Connector Housing and Sockets)
	305-0824	1	Non-PMG Generator - (Newage		338-2786	1	ENBA
			Part Number E000-24030)		338-2787	1	ENA, ENB, ENC, ENAD
	305-0823	1	PMG Generator (Newage Part	44		•	Housing. Connector
	303 3023	•	Number E000-23210)		323-1304	1	6 Place (J2)
254	319-0652	1	Plate, Voltage Regulator		323-1306	1	8 Place (J1)
LUN	313 0001	•		45			
200	915-0544	•	Mounting - PMG Generator	45		11	Socket, Female
238	815-0544	6	Screw, Locking Head	46	353-0094-01	1	Resistor (R1)
			(#6-32 x 1/2") PMG Generator	47	357-0030	1	Rectifier (CR1)
26	332-1043	1	Jumper, Terminal (TB21-22	48	357-0051	1	Diode (CR2)
			to 21)	49	-	1	Relay, Run (See Separate
27	350-1222	1	Resistor (TB21-32 to 26)				Page 23 for Components)

# AC Control Door Assembly



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF	PART NO.	QTY USED	PART DESCRIPTION
1	301-9054-02	1	Door, Control - AC with Three Round Meter Holes	8	308-0882	1	Switch, Rotary - Voltmeter/ Ammeter (Knob Not Included) (S21)
2			Voltmeter (M21)	9	303-0032	1	Knob, Switch - Rotary
	302-1148	1	0-300/600	10	320-1688-01	1	Breaker, Circuit (CB21)
	302-1753	1	0-750				without Auxiliary Contact
3			Ammeter (M22)				
	302-1684	i	0-150/300				
	302-1685	1	0-200/400				
4	302-1720	1	Meter, Frequency (M23)				
5	517-0131	1	Plug, Hole (3/8" Hole)				
6	322-0363	1	Light, Indicator - Upper/ Lower Scale (DS21, DS22)				
7			Potentiometer, Adjust - Voltage (R21)				
	303-0261	1	1.5K Ohms (Used with Model SX440 Voltage Regulator) (Non-PMG Gemerator)				
	303-0285	1	5K Ohms (Used with Model MX321 Voltage Regulator) (PMG Generator)				


# DC Control Door Assembly



900B


REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Door, Control - DC	11	302-0885	1	Meter, Time Totalizing (M14)
	301-9055-02	1	Doors With Three Round Gauge Holes	12	308-0892	1	Switch, Rocker - Restart/ Panel Light (S11)
2	815-0385	4	Screw, Machine - Round Head (#6-32 x 1/2")	13	308-0784	1	Switch, Rocker - Run/Stop/ Remote (S12)
3	870-0183	4	Nut, Hex - With ET (#6-32)	14	517-0131	1	Plug, Hole (3/8" Hole)
4			Light Assembly, Indicator (Includes Wiring Harness and Connector Housing) (A12)	15	193-0250	3	Resistor (Mounted on Oil Pressure, Oil Temperature Gauges, and Water Temperature
	322-0360-02	1	12 Light Assembly			_	Gauges) (R11,R12,R13)
5	322-03 <b>69-</b> 02	1	Light, Indicator - Replacement	16	302-1723	1	Ammeter - Blank Scale
6	322-0361	1	Light, Panel (DS11)	17	301-6257	1	Switch - Blank
7	322-0017	1	Bulb, Panel Light - Replacement	18	308-0853	1	Stop (Includes Bulb) (\$14)
8	193-0352	1	Gauge, Oil Pressure (M11)	19	322-0223	1	Bulb, Pushbutton Switch -
9	193-0351	1	Gauge, Water Temperature (M12)				Replacement
10	302-1642	1	Voltmeter (M13)	21	193-0435	1	Gauge, Oil Temperature

#### Tachometer




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	OTY USED	PART DESCRIPTION
1	302-1873-01	ı	Tachometer (0-4000 RPM) (M16)	3	3021723	1	Ammeter - Blank Scale
-	201-6257	7	Curitain - Dlank				

# Over/Under Frequency (60HZ/\$0HZ)




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	821-Q017	2	Screw, Self-Locking	7	402-0354	1	Mount, Shock
			$(5/16-18 \times 1/2")$	8	301-6987	1	Bracket
2	850-0045	2	Washer, Lock (5/16")	9	338-2124	1	Harness Wiring - OV/UV
3	862-0014	2	Nut, Hex (5/16-18)	10	322-0384-09	1	Light, Indicating
4	860-0008	10	Nut, Hex (#8-32)	11	322-0384-10	1	Light, Indicating
5	856-0002	18	Washer, Lock - EIT	12	301-9941	1	Plate, Mounting - Relay
6			Relay, Over/Under Frequency				
	307-2553	1	50 HZ				
	307-2709	1	60 HZ				



### Wattmeter


REF NO.	PART NO.	OTY USED	PART DESCRIPTION	REF NO.	PART NO.	OTY USED	PART DESCRIPTION
1			Harness, Wiring	7	860-0008	8	Nut. Hex (#8-21)
	338-1936	1	Three Phase "WYE" Connected Generators	8	856-0002	16	Washer, Lock - EIT (#8)
	338-2479	1	Three Phase "DELTA"	9 10	402-0354 319-0030	<b>4</b> 1	Mount, Shock Plate, Support - Transducer
	338-2478	1	Connected Generators Single Phase Connected	11	821-0017	2	Screw. Self-Locking - HWH (5/16-18 x 1/2")
_			Generators 120/240 VAC	12	850-0045	2	Washer, Lock-Spring (5/16")
2	332-1279	11	Terminal, Lug - Forked (For	13	862-0014	2	Nut, Hex (5/16-18)
			No. 6 Screw Mounting)	14	301-6987	1	Bracket, Mounting
3	332-0897	4	Terminal. Lug - Ring (1/4"	15	302-1722	1	Dial. Wattmeter (Less Dial)
			Screw Mounting)	16			Dial. Wattmeter
4	332-0942	14	Tie, Cable		302-1721-03	1	Scale 0-70 kW
5	813-0102	2	Screw, Machine - Round Head		302-1721-04	1	Scale 0-90 kW
			(#10-32 x 5/8")		302-1721-06	1	Scale 0-160 kW
6			Transducer Watt		302-1721-08	1	Scale 0-200 kW
	302-1833-01	1	Three Phase "WYE" Connected Generators	17	301-9054-01	1	Panel, Control
	302~1833~05	1	Three Phase "DELTA" Connected Generators				
	302-1833-04	î	Single Phase, Connected Generators 120/240 VAC				

# Over/Under Voltage Relay




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	307-2552	1	Relay, Over/Under Voltage	9	850-0045	2	Washer, Lock - Spring (5/16")
			(120VAC) (A17)	10	862 -0014	2	Nut, Hex (5/16-18)
2	338-2123	1	Harness, Wiring-Over/bader Voltage	11	812-0082	4	Screw, Machine - Round Head (#8-32 x 3/4")
3	301-9933	ì	Plate, Relay Mounting	12	307-1911	1	Relay, Time Delay (.1 to 10
4	301 6987	1	Bracket, Relay Mounting				Seconds) (K17)
5	402-0354	4	Mount . Shock	13	323-0804	1	Socket Relay
6	856-0002	18	Washer, Lock - EIT	14	322-0384-09	i	Light Indicator Marked
7	860-0008	12	Nut., Hex (#8-32)				"O/U Volt"
8	821-0017	2	Screw, Cap - Self-Locking	15	332~0898	ī	Terminal, Ring:
-			(5/16-18 x 1/2")	.6	332-0942	3	Tie Cable

### **Current Transformer**




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1.			Transformer, Current				
	302-1845-04	3	Ratio 100/5;200/5				
	302-1845-05	3	Ratio 150/5;300/5				
	302-1845-06	3	Ratio 200/5:400/5				
2	338-2229	1	Harness, Wiring				
3	332-1389	8	Tie, Wire				

Run Relay




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	307-1056	3	Relay, Run (K11)	_	319-0447	1	Bracket, Relay Mounting
2	815-0388	4	Screw, Pan Head - Cross Recessed Thread (#6-32 x 1/2")	•	323-0804 307-1987	6	Socket, Relay Holddown, Relay

Electronic Overspeed Module




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	812-0084	4	Screw, Machine - Round Head (#8-32 x 1/2")	-	319-0754 338-2493	1	Plate, Mounting - Module Harness, Wiring (A16 to A11
2	305-0818-02		Module, Overspeed - 24 VDC (Frequency Detection Module)				and AUX-P2,P3)
3	815-0544	4	Screw, Cap - Hex Head with ET Lockwasher (#6-32 x 1/2")				

### Voltage Regulator




REF	PART NO.	QTY USED	PART DESCRIPTION	REF NO.		QTY	PART DESCRIPTION
	22. 22.2						
T	305-0848-01	ī	Bracket; Mounting - Regulator	12	303-0261	1	Potentiometer
2	305-0824	I	Regulator, Voltage	13	· .		Harness, Wiring
∵ 3	815-0793-03	6	Screw, Flange - Locking		338-2549	1	Regulator
			(M5 x .8 x 12mm)		338-2548	1	Generator
4	815-0793-07	4	Screw, Flange - Locking		338-2609	1	Circuit Breaker
			$(M5 \times .8 \times 30mm)$		338-2547	1	Permanent Magnet Exciter
5	232-3536	1	Base, Block - Terminal	14			Lead
6	332-3107	1	Block, Terminal		226-4084-01	1	Jumper
7	815-0792-08	3	Screw. Pan Head		226-4162	1	Breaker, Circuit
•		_	(M4 × .7 × 30mm)	15	850-2005	10	Washer, Lock (M5)
8	850-2004	3	Washer, Lock - Spring (M4)	16	526-2060	10	Washer, Flat (M5)
10	320-1688-01	1	Breaker, Circuit				` ' '

# Control Space Heater



REF	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	98-3232	3	Decal, Warning (Shock Hazard)	10	526-0113	2	Washer, Flat (5/16")
2	870-0183	2	Nut, Self-Locking - Hex (#6-32)	11	870-0257	2	Nut, Self-Locking - Hex
3	854-0006	4	Washer, Lock - IT (#6)	ΛI	070-0237	2	(5/16-18)
4	301-1886	1	Cover	12	130-1107	2	Spacer
5	860-0006	2	Nut, Hex (#6-32)	13		-	Heater, Electrical
7	812-0070	2	Screw, Machine - Round Head (#6-32 x 1-1/4")		333~0151	1	75 Watt, 120 VAC
8	309~0128	1	Thermostat - Adjustable	14	335-0161	1	Cable, Electrical, 120 VAC
9	600-0034	2	Screw, Cap - Hex Head (5/16-18 x 2-1/4")				


950B



### Generator Heater

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Kit, Heater-Generator Includes Parts Marked *}	9	332-3023	1	*Block, Terminal (Newage Part Number 003-14010)
	333-0445	1	120 Volt (Newage Part Number 330-AH02)	10 11	508-0228 98-6142	1 1	*Grommet *Label, Heater ADJ
2			*Cartridge, Heater	12			*Label, Volts/Watts
	333-0438-07	1	120 Volt (Newage Part Number 071-31057)		98-6143	1	120 Volts/280 Watts (Newage Part Number 450-13650
3	332-3024-11	2	*Clamp, Loop (Newage Part Number 052-46058)		98-6233	1	240 Volts/210 Watts (Newage Part Number 450-13640)
4	815-0766	4	*Screw, Head-Pan (M4 x 16)	13	822-3047	1	*Screw, Head-Pan (M3 x 20)
5	860-2005	2	*Nut. Hex (M4)	14	850-2003	1	*Washer, Lock-Spring (M3)
6	850-2004	4	*Washer, Lock-Spring (M4)	15	330-0141-04	1	*Gasket, Box-Terminal
7	526-2050	2	*Washer, Flat (M4)	16	898-1254-19	1	*Sleeving, CL200 Insulation
8	330-0142	1	*Terminal, Box-Heater (Newage Part Number 450-10060)	17 18	330-0141-03 815-0446	1 2	*Cover, Box-Terminal Screw, RH x Rec W/IT

<sup>\* -</sup> Parts Included in 333-0445 Generator Heater Kit.




### Generator (UC22)

REF NO.	PART NO.	QTY USE		REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1 2	805-0615	8	Bolt, Place (3/8-16 x 3/4") Screw, Cap - Hex Head	33	508-0139	-	Seal, Edging (Order by the foot - 3 feet required)
	800-0051	8	$3/8-16 \times 1-1/4$ "	34			Cover, Stator - Upper
٠,	800-0053	4	3/8-16 × 1-3/4"		234-0916-01	1	(180/240 Stack Length)
3	800-2087	8	Screw, Cap - Hex Head $(M10 \times 1.5 \times 30)$	35	234-0916-02	1	(300 Stack Length) Cover, Stator - Lower
4 5	850-0050	12	Washer, Lock - Spring (3/8)		232~3430~02	1	(180/240 Stack Length)
6	850-2010 526-0174	8	Washer, Lock - Spring (M10)	20	232-3430-03	1	(300 Stack Length)
7	232-3452	2	Washer, Flat (3/8") Feet, Generator Mounting	36	800-2086	10	Screw, Cap - Hex Head
12	202 0102	€.	Stator	37	850-2010	10	(10 x 25)   Washer, Lock - Spring (M10)
	220-4289-34	1	(240 Stack Length)	38	526-2120	10	Washer, Flat (MIO)
		-	(50H/60H, BR, 12L, 105°C)	41	517-0135	1	Plug
	220-4289-35	1	(300 Stack Length)	42	526-0213	6	Washer, Flat (M8)
	220-4289-39	1	(50H/60H, 12L, BR, 80-105°C) (240 Stack Length)	43	800-2058	6	Screw, Cap - Hex Head (M8 x 25)
			(60H, Low R, 12L, 105°C)	44	850-2008	6	Washer, Lock - Spring (M8)
	220-4289-40	1	(300 Stack Length)	45	234-0863	2	Guard, Fan
			(60H, Low R, 12L, 80-105°C)	46	234-0878	2	Screen, Air Inlet
4.0	220-4289-45	1	(300 Stack Length) (60H, 600, 6LR, 80-105°C)	47	821-2020	8	Screw, Locking - Flange (M5 x 10)
13	201 2404 24		Rotor Assembly (Includes Parts Marked *)	48	815-0793-03	8	Screw, Hex - Flange (M5 x .8 x 12)
	201-3484-04	1	(240 Stack Length)	49	850-2005	8	Washer, Lock - Spring (M5)
1.4	201-3484-05 515-0298-02	1	(300 Core Length)	50	211-0422	1	Bell, End
14 15	201-3434-02	1	*Key (180 and 240 Core Length) *Rotor Assembly, Exciter	51	232-3441	6	Washer, Flat
10	201 0404 02		(Includes Parts Marked ¶) (Newage Part Number	52 53	850-2008 800-2058	6 6	Washer, Lock - Spring (MB) Screw, Cap - Hex Head (M8 x 25)
			210-1037) (240 and 300 Core	54	850-2006	4	Washer, Lock - Spring (M6)
			Length)	55	800-2042	4	Screw, Cap - Hex Head (M6)
16	357-0091	1	**Rectifier Assembly, Forward	56	220-4293-05	1	Stator, Exciter (Newage
			(Includes Diodes)				Part Number 230-1001)
17	357-0092	1	**Rectifier Assembly, Reverse				(40 Core Length)
40	250 4505 44		(Includes Diodes)	57	526-2100	3	Washer, Flat (M8)
18	358-0135-01	3	**Diode, Positive (Forward)		850-2008	3	Washer, Lock - Spring (M8)
19	358-0135-02	3	Includes Lead ****Diode, Negative (Reverse)	59 60	232-3421	1 3	Block, Main Terminal
20	304-0807	1	Includes Lead  *Varistor		800-2060	_	Screw, Cap - Hex Head (M8 x 1.25 x 35)
21	510-0165	i	*Bearing, Ball	61 62	508-1057 150-2309	1 1	Grommet Bracket, Overspeed Switch
22	518-0122	ī	*Ring, Retaining	63	150-0956	i	Switch, Overspeed
	821-2021	Ž	*Screw, Cap - Locking Head		150-0723	i	Point, Overspeed
		-	(M5 × 12)		870-0250	ī	Nut, Insulated
24	509-0266-01	1	Ring, "O"	66	862-0001	2	Nut, Hex (1/4-20)
25	231-0316	1	Adapter, Generator (SAE 2)	67	853-0013	1	Washer, Lock - ET (1/4")
26	800-2090	6	Screw, Cap - Hex Head	68	856-0010	1	Washer, Lock - EIT (3/8")
			$(M10 \times 45)$	69	800-2087	1	Screw, Cap - Hex Head
27	850-2010	å	Washer, Lock - Spring (M10)				(M10 x 30mm)
28	720-1119	ઇ	Screw, Cap - Hex Head (M16 x 40)	70	526-0240	1	Washer, Flat (13/32" ID x 1-1/2" OD x 1/8" Thk)
29	232-3443	2	Disc, Generator Drive (SAE 11.5)		821-2020	4	Screw, Self-Locking - Hex Washer Head (M5 x 10mm)
	232-3593	1	Hub, Generator Drive		234-0875-01	1	Cover, End Sell
	526-0259	B	Washer, Flat (M16)	73	232-3462-01	4	Spacer, Cover
32	231-0318	1	Ring, Adapter	74	526-2080	4	Washer, Flat (M6)

NOTE: When ordering rotor and stator parts, furnish complete model, spec and serial number of the generator set.

<sup>\* -</sup> Parts Included in Rotor Assembly.
¶ - Parts Included in Exciter Rotor Assembly.




#### Generator (UC27)

REF NO.	PART NO.	QTY USE		REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	805-0015	8	Bolt, Place (3/8-16 x 3/4")	45	001 0015	4	* * * * * * * * * * * * * * * * * * *
2	800-0051	12	Screw, Cap - Hex Head	25 26	231-0317	1	Adapter, Generator (SAE 2)
***	300 0001	A 4	(3/8-16 × 1.75)	20	800-2091	5	Screw, Cap - Hex Head M10 x 56mm
3	800-2113	8	Screw, Cap - Hex Head		800-2093	1	M10 x 50mm
			$(M12 \times 1.75 \times 35mm)$	27		6	Washer, Lock - Spring (M10)
4	850-0050	12	Washer, Lock - Spring (3/8)	28	720-1119	8	Screw, Cap - Hex Head
5	850-2012	3	Washer, Lock - Spring (M12)				(M16 × 40mm)
6	526-0174	Ę	Washer, Flat (M12)	29	232-3443	3	Disc, Generator Drive
7 12	232-3454	5	Feet, Mounting - Generator				(SAE 11.5)
12	220-4298-31	1	Stator Assembly, Generator	30	232-3593	1	Hub, Orive - Generator
	550.4530.3T	+	(165 Stack Length)	31		8	Washer, Flat (M16)
	220-4298-32	1.	50H/60H, BR, 12L-80°C (190 Stack Length)	32 33	231-0319 508-0139	1	Ring, Adapter
	220 4200 02	1.	50H/60H, 1 PFO, 12L-105°C	33	200-0138	_	Seal, Edging (Order by the Foot - 3 Feet Required)
			50H/60H, BR, 12L-80°C/105°C	34			Cover, Stator - Upper
	220-4298-33	1	(230 Stack Length)	0 -	234-0917-01	1	(165/190 Stack Length)
			50H, 1PFO, 12L-80°C		234-0917-02	ī	(230/285 Stack Length)
			50H, BR, 12L-105°C		234-0917-03	1	(335 Stack Length)
	220-4298-34	1.	(285 Stack Length)	35			Cover, Stator - Lower
			50H/60H, 1PFO, 12L-105°C		234-0853-01	1	(165/190 Stack Length)
	220-4298-35	λ	(335 Stack Length)		234-0853-02	1	(230/285 Stack Length)
	220-1200-24	4	50H/60H, BR, 12L-80°C/105°C		234-0853-03	1	(335 Stack Length)
	220-4298-37	1.	(165 Stack Length)	36	800-2112	10	Screw, Cap - Hex Head
			50H, BR, 12L-105°C 60H, Low R, 12L-80°C	37	850-2012	10	(M12 x 30)
	220-4298-38	1	(190 Stack Length)	38		10	Washer, Lock - Spring (M12) Washer, Flat (M12)
			60H, Low R, 12L, 105°C	41		ĭ	Plug
	220-4298-39	1	(230 Stack Length)	42	526-0077	6	Washer, Flat (M10)
			60H, Low R, 12L, 80°C	43	800-2087	6	Screw, Cap - Hex Head
	220-4298-43	L	(165 Stack Length)				$(M10 \times 30mm)$
			60H, 600, 6LR, 80°C/105°C	44	850-2010	6	Washer, Lock - Spring (M10)
	220-4298-44	1	(190 Stack Length)	45		2	Guard, Fan
	000 4000 45		60H, 600, 6LR, 105°C	46	234-0879	2	Screen, Inlet - Air
	220-4298-45	1	(230 Stack Length)	47	821-2020	8	Screw, Cap - Locking Head
13			60H, 600, 6LR, 80°C/105°C Rotor Assembly	48	815-0793-03	8	(M5 x 10mm) Screw, Cap - Locking Head
***	201-3485-01	1	(165 Stack Length)	40	010 0190 00	O	$(M5 \times .8 \times 12mm)$
	201-3485-02	ī	(190 Stack Length)	49	850-2005	8	Washer, Lock - Spring (M5)
	201-3485-03	1	(230 Stack Length)	50	211-0423	1	Bell, End
	201-3485-04	1	(285 Stack Length)	51	526-0077	6	Washer, Flat (M10)
	201-3485-05	1	(335 Stack Length)	52	850-2010	6	Washer, Lock (M10)
14	-1		*Key	53	800-2087	6	Screw, Cap - Hex Head
	515-0298-02	1	(165/190 Stack Length)	- 4	000 0000		(M10 × 30)
15	515-0298-03	1	(230/285/335 Stack Length)	54	850-2006	4	Washer, Lock - Spring (M6)
10			*Rotor Assembly, Exciter (Includes Parts Marked ¶)	5 <b>5</b>	800-2042	4	Screw, Cap - Hex Head $(M6 \times 1 \times 60)(165/190 \text{ Stack})$
	201-3434-02	1	(165/190 Stack Length)		800-2046	4	$(M6 \times 1 \times 60)$
	201-3434-03	ī	(230/285/335 Stack Length)			•	(230/285/335 Stack Length)
16	357-0091	1	*¶Rectifier Assembly, Forward	56			Stator, Exciter
			(Includes Diodes)		220-4293-05		(Newage Part No. 230-1001)
17	357-0092	1	*¶Rectifier Assembly, Reverse				(165/190 Stack Length)
		_	(Includes Diodes)		220-4293-06		(Newage Part No. 330-0100)
18	358-0135-01	3	*"Diode, Positive (Forward)			_	(230/285/335 Stack Length)
10	250 0125 02	~	Includes Lead	57	526-2100	3	Washer, Flat (M8)
19	358-0135-02	3	***Diode, Negative (Reverse)	58 50	850-2008	3	Washer, Lock - Spring (M8)
20	304-0807	1	Includes Lead *Varistor	59 60	232-3421 800-2060	1 3	Block, Terminal - Main Screw, Cap - Hex Head
	510-0164	1	*Bearing, Ball	UU	500 Z000	J	(MC × 1.25 × 35mm)
22	518-0083	ī	*Ring, Retaining	61	508-1057	1	Grommet
23	821-2021	2	*Screw, Cap - Locking Head	62	150-2309	î	Bracket, Switch - Overspeed
•			$(M5 \times 12)$	63	150-0956	1	Switch, Overspeed
24	509-0266-02	1	Ring, "O"	64	150-0723	1	Point, Overspeed

NOTE: When ordering rotor and stator parts, furnish complete model, spec and serial number of the generator set.

<sup>\* -</sup> Parts Included in the Rotor Assembly.


\* - Parts Included in the Exciter Rotor Assembly.



### Generator (UC27)


REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
65	870-0250	1	Nut, Insulated	72	234-0875-01	1	Cover, End Bell
66	862-0001	2	Nut, Hex (1/4-20)	73	232-3462-01	4	Spacer, Cover
67	853-0013	ī	Washer, Lock - ET (1/4")	74	526-2080	4	Washer, Flat (M6)
68	856-0010	1	Washer, Lock - EIT (3/8")	75	332-2987	4	Link, Termina:
69	800-2087	1	Screw, Cap - Hex Head	76	526-2120	8	Washer, Flat (M10)
			$(M10 \times 30mm)$	77	850-2010	8	Washer, Lock (M10)
70	526-0240	1	Washer, Flat (M10)	78	860-2009	8	Nut, Hex $(M10 \times 1.5)$
71	821-2020	4	Screw, Self-Locking - Hex Washer Head (M5 x 10mm)				

# Permanent Magnet Exciter




REF NO.	ON/AN PART NO.	NEWAGE PART NO.	QTY USED	PART DESCRIPTION	REF NO.	ONAN PART NO.	NEWAGE PART NO. 1	QTY USED	PART DESCRIPTION
2 3 4	775-0049 201-3446 220-4233 232-3511 232-3462-02	054-20505 130-20136 420-17200 130-20101 450-14370	1 1 1 4	Pin, Dowel Rotor, Exciter Stator, Exciter Clamp, Stator Spacer, Mounting -	7 8 9	234-0875-02 249-0462 815-0761-01 850-2010 821-2020	450-14360 450-22000 350-14950 028-31509	1	Cover, Bell - End Harness, Wiring Bolt (M10 x 1.5 x 110) Washer, Lock - Spring (M10) Screw, Locking - Hex Head
-	2.22			Corner	- "	7-1			Flange (M5 x 0.8 x 10)

# Entrance Box



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	301-9668	1	Box, Entrance				
2	301-9669	2	Panel				
3	301-9975	. 1	Cover				
: 4	821-0010	16	Screw, Hex Washer Head -		* .	:	



#### Circuit Breaker

REF NO.	PART NO.	WEED OTY	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	821-0010	8	Screw, Cap - Self-Locking $(1/4-20 \times 1/2")$				With Auxiliary Contacts 600 Volt, 2 Pole
2			Cover, Breaker - Circuit		320-1556-12	1	300 Ampere
	301-9892	1	240 Volt, 2 Pole, 240 Volt 3 Pole (250-400 Amp)		320-1556-13 320-1556-14	1 1	350 Ampere
	301-9682	1	480 Volt, 3 Pole, 600 Volt.		320-1516-10	1	400 Ampere 450 Ampere
	201 9005	2	3 Pole		320-1516-11	i	500 Ampere
	319-0285	1	240 Volt, 3 Pole				480 Volt, 3 Pole
			(200-225 Amp)		320-1462-27	1	90 Ampere
3	800-0028	5	Screw, Cap - Hex Head		320-1462-28	1	100 Ampere
	F00 0000	-	(5/16-18 × 1")		320-1462-30	1	125 Ampere
4 5	526-0022 850-0045	5 5	Washer, Flat (5/16") Washer, Lock - Spring (5/16")		320-1462-31	1	150 Ampere 600 Volt, 3 Pole
6	862-0015	5	Nut, Hex (5/16-18)		320-1462-44	i	90 Ampere
7	001 0010	•	Screw, Machine - Round Head		320-1462-45	ī	100 Ampere
	812-0165	4	$(1/4-20 \times 4-1/2")$ 240 Volt,		320-1462-47	1	125 Ampere
			3 Pole		320-1462-48	1	150 Ampere
	812-0157	4	(1/4-20 x 1-3/4") 240 Volt,		200-1462-00	1	480/600 Volt, 3 Pole
			2 Pole, 600 Volt 2 Pole (250 Amp and Above)		320-1463-08 320-1463-09	1 1	175 Ampere 200 Ampere
	812-0157	4	1/4-20 x 1-3/4" - 240 Volt,		320-1463-10	i	225 Ampere
	012 010.	-	3 Pole, 480/600 Volt,		320-1464-06	ī	250 Ampere
			3 Pole (175,200,225 Amp)		320-1464-07	1	300 Ampere
	812-0094	4	(#8-32 x 3-5/8") 480/600		320-1464-08	1	350 Ampere
	010 0110		Volt, 3 Pole		320-1464-09	1	400 Ampere
	813-0118	4	480/600 Volt, 3 Pole (175,200,225 Amp)		320-1464-10	1	450 Ampere 240 Volt, 3 Pole
8			Washer, Lock - Spring		320-1556-09	1	200 Ampere
•	850-0040	4	1/4"		320-1556-10	1	225 Ampere
	850-0025	4	#8		320-1556-15	1	250 Ampere
9			Washer, Flat		320-1556-16	1	300 Ampere
	526-0108	4	1/4"		320-1556-17	1 1	350 Ampere
10	526-0048 301-9669	4 2	#8 Panel, Box		320-1556-18	1	400 Ampere With Shunt Trip
11	301-9668	i	Box, Breaker				240 Volt, 3 Pole
12	001 0000	_	Breaker, Circuit		320-1557-56	1	300 Ampere
			240 Volt, 2 Pole		320-1557-58	1	400 Ampere
	320-1555-12	1	300 Ampere		222 1422 27	4	480 Volt, 3 Pole
	320-1555-13	1 1	350 Ampere		320-1466-27 320-1466-28	1 1	90 Ampere 100 Ampere
	320-1555-14 320-1513-10	1	400 Ampere 450 Ampere		320-1466-30	1	125 Ampere
	320-1513-11	î	500 Ampere		320-1466-31	ī	150 Ampere
	320-1513-12	1	600 Ampere				600 Volt, 3 Pole
			240 Volt, 3 Pole		320-1467-08	1	175 Ampere
	320-1555-09	1	200 Ampere		320-1467-09	1 1	200 Ampere 225 Ampere
	320-1555-10 320-1555-15	1 1	225 Ampere 250 Ampere		320-1467-10	1	W/Shunt Trip & Qux Contacts
	320-1555-16	1	300 Ampere				480 Volt, 3 Pole
	320-1555-17	ī	350 Ampere		320-1486-27	1	90 Ampere
	320-1555-18	1	400 Ampere		320-1486-28	1	100 Ampere
			480 Volt, 3 Pole		320-1486-30	1	125 Ampere
	320-1458-27	1	90 Ampere		320-1486-31	1	150 Ampere 600 Volt, 3 Pole
	320-1458-28 320-1458-30	1 1	100 Ampere 125 Ampere		320-1487-08	1	175 Ampere
	320-1458-31	1	150 Ampere		320-1487-09	i	200 Ampere
	320 1400 01		600 Volt, 3 Pole		*** <b>-</b>		
	320-1458-44	1	90 Ampere				
	320-1458-45	1	100 Ampere				
	320-1458-47	1	125 Ampere				
	320-1458-48	1	150 Ampere 480-600 Volt, 3 Pole				
	320-1459-08	1	175 Ampere				
	320-1459-09	1	200 Ampere				
	320-1459-10	î	225 Ampere				
	320-1460-06		250 Ampere				
	320-1460-07	1	300 Ampere			•	
	320-1460-08	1	350 Ampere				
	320-1460-09 320-1460-10	1	400 Ampere 450 Ampere				
	250 T400-10	1	TOO MILES C				